



GM9907-L2

user's manual

GM9907-L 2 01902 0 0

V0 2 .00.00

© 2018, Shenzhen Jieman Technology Co., Ltd., all rights reserved.

No unit or individual may copy, distribute, transcribe or translate into other language versions in any form or by any means without the permission of Shenzhen Jieman Technology Co., Ltd.

As our products have been continuously improved and updated, our company reserves the right to modify this manual at any time without prior notice . To do this, please visit the company website frequently to get timely information.

Company website <http://www.szgmt.com>

Implementation standards of this product : GB/T 7724—2008



Overview

The GM9907 Packaging Controller is a new weighing control instrument specially developed for the single scale incremental method automatic quantitative packing scale. The controller English display interface for


easy operation; completely new algorithm faster and more accurate control so that the load; the USB port and dual port serial device to make it easier to system interconnect. Can be widely used in feed, chemical, food and other industries that require quantitative packaging equipment.

1.1 features and features

- English display interface make operation easier and more intuitive
- There are five modes of bagging application, hopper, non hopper, big mouth, servo motor, PLC.
- **28**-digital input and output control (**12** in / **16** out), the input and output port positions can be customized.
- Switching quantity test function, convenient for debugging of packing scale
- Fully automatic double material speed, three material speed feeding control, with jog feeding function
- Twenty formulas can be stored to facilitate packaging of different range materials
- USB interface facilitates import and export of various parameters
- Feed control function, convenient control connection between packaging scale and front feeding equipment
- Feed speed adaptive function
- IO auxiliary logic programming
- Automatic drop correction function
- Multiple digital filtering
- Batch setting function
- Bag making function, suitable for packaging of powder materials
- Automatic zero tracking
- Time / date function
- Three-level user identity setting
- Dual serial port, external serial printer, computer or second display

- With network port communication function ,it is convenient to communicate with the host computer

1.2 front panel description




Interface 1 description :

User information, weight status area , alarm prompt bar and function parameter area are retained . Increase the parameter display area and shortcut keys for easy setting

1 : Parameter display area : Display the relevant parameters of the current recipe.

2: Shortcuts: increased 8 customizable shortcuts, setting.

1.3 rear panel description



1.4 Technical Specifications

1.4.1 General Specifications

Power source: **DC24V**

Power filter: included

Operating temperature: **-10 ~ 40 °C**

Maximum humidity: **90% RH** non-condensing

Power consumption : about **15 W**

Physical dimensions : **190 mm × 124 mm × 48 mm**

1.4.2 analog part

Sensor power source : **DC 5 V 125 mA (MAX)**

Input impedance : **10MΩ**

Zero adjustment range: **0.002 ~ 15 mV** (when sensor **3mV / V**)

Input sensitivity: **0.02uV / d**

Input range

:

0.02 ~ 15mV

Conversion mode :

Sigma-Delta

A/D conversion speed: **120 , 240 , 480 , 960** times / sec

Non-linear: **0.01% FS**

Gain drift: **10PPM / °C**

Show the highest degree of precision: **1 / 100,000**

1.4 .3 digital part

Display: **7** inch resistive touch screen

Negative Number Display: **"-"**

Overload Display: Chinese "overrange wt / sensor signal is too small."

Decimal point position: **5** optional


2. installation

2.1 General principles

- 1) Open the hole in the appropriate position of the control cabinet (opening size **179 (± 1) mm** × **113 (± 1) mm**)
- 2) Load the meter into the control cabinet.
- 3) Remove the side strips from the accessories, fix them on both sides of the meter, and fix them with **M3*10** screws.

2.2 Sensor connection

The **GM9907** package controller can be connected to a resistive strain bridge sensor. When using a six-wire sensor, the sensor's **SN+** and **EX+** must be shorted , and **SN-** and **EX-** should be shorted .




EX+ : Power supply is positive **EX-** : Power negative **SN+** : Sensing positive **SN-** : Inductive negative **SIG+** : Positive signal **SIG-** : negative signal


2.3 switch interface connection

GM 9907 package controller **28** comprises a switch input, output control (the 12/16). The photoelectric isolation mode is adopted, and the internal power supply of the instrument is driven. Meter switch input is active

low; output open-collector transistor output taken, each line of the drive current up to **5 00m A**, the maximum full load current of **3A**. The terminal wiring is as shown below:



Switch input interface diagram




Switch output interface diagram

GM 9907 packaging controller to switch the user can customize the way, to facilitate the user lines and some special applications, digital content See Section 3.7.


2.4 power connection

The **GM9907** package controller uses a **24V** DC power supply. The connection is as shown below:




2.5 serial port connection


The **GM9907** provides two serial communication interfaces as shown in the figure below. The serial port one is **RS - 232** mode (terminal port **TX D** , **RX D** , **GND**); the serial port 2 is **RS - 485** , (terminal port **A** , **B** , **GND**). Serial port support: **MODBUS** protocol, continuous mode and print format .



Instrument and computer connection diagram



Instrument and computer connection diagram (**RS-232** mode)



Instrument and host computer connection diagram (**RS-485** mode)

2.6 touch screen calibration

The touch screen needs to be calibrated when the new product is used for the first time or after a long time. The touch screen calibration method:

Power on the **GM9907** , and press and hold the touch screen at any time . The system **switches** to the touch screen calibration interface. Press and hold the cursor position on the screen to complete the calibration. After the coordinates of the point are displayed, the screen will automatically enter the next calibration point. Follow the change of the cursor position and press and hold, the calibration is completed, and the interface displays

the coordinates of the five calibration points, and then automatically enters the main interface of the product. If you enter the touch screen calibration interface by mistake, you can exit the interface by pressing the “Cancel” button in the lower right corner.

3 menu

Click the system menu to enter the parameter menu and query and modify each parameter.

Administrator	0:Target	1:Time Parameter	2:Over/Under Parameter
1.Recipe	3:Auto Free Fall Correction Parameter	4:Jog Flow Parameter	5:With Hopper
2.Sys&Com	6:No Hopper Parameter	7:PLC Parameter	8:Ton Scale Parameter
3.Peripherals	8:Valve Scale Parameter		
4.Motor	Recipe ID: 1 Target: 100.00kg		
5.Calibration			
6.ACUM And Batch			
7.I/O Module			
8.User Logic			
9.User Manage			
10.System Info.	Return		

The system menu interface is as shown in the figure above. The left side is the parameter item list, and the right side is the parameter item brief description and some parameter item information.

- ◆ Click the sub-option button to enter the current parameter item to view and set the attribution parameter information.
- ◆ Press [Back] to exit the current interface and return to the previous interface.

menu	Parameter item	parameter list	Parameter Description
system System dish single	Recipe parameters	0: Quantitative value	Set the package weight value related parameters
		1 : time parameter	Set the delay time related parameters of the feeding process
		2 : Super poor parameter	Set parameters such as excess weight, mode, and feeding
		3: Drop correction parameter	Set the difference correction method, correction range and other related parameters
		4: Slow plus jog parameters	Set slow plus jog switch, time and other related parameters
		5: There are bucket scale parameters	Set the relevant parameters of the bucket scale structure
		6: No hopper scale parameters	Set the relevant parameters of the hopper less scale structure

		7: PLC parameters	Set the state of the PLC parameters
		8: ton package scale parameters	Set the relevant parameters of the ton package scale structure
		9: Valve port scale parameters	Set the relevant parameters of the valve port scale structure
	System and communication	0: weight parameter	Set the judgment, clear, and other weight parameters
		1: Filter parameters	Set filter switch, filter level
		2: Function parameters	Set parameters such as adaptive and fixed value
		3: scale body structure	Select the scale body structure, feeding method, etc.
		4: Serial port(232)	Set serial port (RS 232) related parameters
		5: Serial port (485)	Set serial port (RS485) related parameters
		6: Network port	Set network port related parameters
	Peripheral parameters	0: bag parameters	Set the number of shots, the number of times and other parameters
		1: coding parameters	Set the relevant parameters of the coding mechanism
		2: Conveyor parameters	Set the relevant parameters of the conveyor
		3: Print parameters	Set parameters for automatic printing function
		4 : sewing machine parameters	Set sewing machine, thread cutting machine and other related parameters
		5: Unloading rapping parameters	Set parameters such as discharge rapping time and number of times
		6: Adding and discharging timeout judgment	Set the parameters related to the loading and unloading timeout
		7: Auxiliary pulse parameters	Set the relevant parameters of the auxiliary pulse
	Motor parameters	0: Motor parameters	Set recipe number, motor group number
		1; feeding parameters	Set feed related parameters
		2: Clip loose bag parameters	Set the relevant parameters of the clip loose bag
		3: Discharge parameters	Set discharge related parameters
	School scale	0: weighing parameter	Set parameters such as unit, decimal point, range, etc.

	1: weight calibration scale	Performs calibration operation for calibrating the meter weight value
Cumulative and batch	0: total accumulation and batch	View, clear, print the total cumulative information
	1: Formula accumulation (1 -10)	View, clear, print recipe(1-10) package accumulation information
	2: Formula accumulation (11-20)	View, clear, print recipe(11 - 20) package accumulation information
	3: User accumulation	View cumulative parameters for different users
Switch	0: Digital input definition	Define the meaning of the meter input port
	1: Switch output definition	Define the meaning of the meter output port
	2: Switch input test	Test whether the connection of each input port is normal.
	3: Switch output test	Test whether each output port is connected properly.
Auxiliary logic parameter	0: Auxiliary logic-1	Auxiliary logic 1function customization
	1: auxiliary logic-2	Auxiliary logic 2 function customization
	2: Auxiliary Logic-3	Auxiliary logic 3 function customization
	3: Auxiliary Logic-4	Auxiliary logic 4 function customization
	4: Auxiliary Logic- 5	Auxiliary logic 5 function customization
	5: Auxiliary Logic- 6	Auxiliary logic 6 function customization
User Management	0: User login	View or switch users
	1: User editing	Edit user permissions, passwords, etc.
	2: Automatic login	Set up automatic login users
system message	0: Version information	View software version and set system time
	1: password management	Password management of various parameters (calibration, cumulative clear password switch must be on)
	2: reset / backup	Restore various parameters to factory settings and data backup
	3: USB data export	Out operation from the instrument guide,formulation, peripherals, motor, calibration,switch parameter, the serial port parameters

		4: USB data import	Import work, recipes, peripherals, motors, calibration, switch parameters, serial parameters to the meter
		5: Short cut definition	Define debug interface shortcuts
		6: Other settings	Select language, adjust screen brightness, set screen saver

3.1 formulation parameters

Administrator	0:Target	1:Time Parameter	2:Over/Under Parameter
1.Recipe	3:Auto Free Fall Correction Parameter	4:Jog Flow Parameter	5:With Hopper
2.Sys&Com	6:No Hopper Parameter	7:PLC Parameter	8:Ton Scale Parameter
3.Peripherals	8:Valve Scale Parameter		
4.Motor			
5.Calibration			
6.ACUM And Batch			
7.I/O Module	Recipe ID: 1 Target: 100.00kg		
8.User Logic			
9.User Manage			
10.System Info.	Return		

Recipe parameter item	parameter	Description
Quantitative value	Used to set the package weight value related parameters	
	1 Recipe	Select the recipe number . Initial value: 1 ; Range: 1~20 .

	number	
	2. Target value	Quantify the target value.
	3. quickly increase the amount of advance	In the quantification process, if the weighing value \geq the target value - fast increase the advance amount, the quick addition is turned off .
	3. before touching the amount	In the process of quantification, if the weighing value \geq the target value - the medium plus the advance amount, the middle plus is turned off.
	5. drop value	In the quantification process, if the weighing value \geq the target value - the falling value, the slow addition is turned off.
	6. zero zone value	During the quantification process, if the weighing value is \leq zero zone value, the discharge delay timer is started.
Time parameter	Used to set the delay time related parameters of the feeding process	
	1 before the addition Delay	In the metering bucket mode, when the quantitative process starts, after the delay time, the meter will judge and stabilize (if it does not meet the clear interval condition, it will not judge and not clear), and then start the feeding process; In the no-measure bucket mode, after the pocket is completed, after the delay time, the meter is judged to be stable and peeled. Initial value: 0.5 ; Range: 0.0~99.9 . (Unit: s)
	2. The quick feed ban sentenced to time	At the beginning of the quantification, during this time, in order to avoid overshoot, no weight judgment is made, and the quick addition is always effective. Initial value: 0.9 ; Range: 0.0~99.9 . (Unit: s)
	3. Canada banned sentenced to time	After the end of quick feed, in this case between, in order to avoid overshooting the weight determination is not performed, has been effectively added. Initial value: 0.9 ; Range: 0.0~99.9 . (Unit: s)
	4. slow feed ban sentenced to time	After added, this time in between, in order to avoid overshooting the weight determination is not performed, the slow feed has been effective. Initial value: 0.9 ; Range: 0.0~99.9 . (Unit: s)
	5. Setpoint hold time	When the setting method is selected as “delay setting”, after the slow feeding is turned off (or the super-defect difference is turned on, the super-defect alarm is finished), the setting value is started, and the holding time is passed, and the fixed value is considered to be finished, and the next process is entered. . Initial value: 0.5 ; Range: 0.0~ 99.9 . (Unit: s)
	6. After a	After the bag signal is given, after the delay, the meter judges

	delayfolder bag	that the bagging operation is completed. Initial value: 0.5 ; Range: 0.0~99.9 . (Unit: s)
	7. Pine bags before delay	After the bucket mode discharge is completed, the loose bag signal is output after the delay time; After the no-bucket mode setting (beat bag) is completed, the loose bag signal is output through this delay. Initial value: 0.5 ; Range: 0.0~99.9 . (Unit: s)
	8.Discharge Delay	During the unloading process, when the weight value of the weighing bucket is less than the zero zone value, the delay is started, and the time delay is closed to close the discharging signal. Initial value: 0.5 ; Range: 0.0~99.9 . (Unit: s)

Super poorparameter	Used to set parameters related to excess weight, mode,feeding, etc.	
	1 under super heterodynedetection switch	“ On / Off ” is optional. When this parameter is set to “ On ” , the quantitative process judges the excess error.
	2. Super owe differencepause switch	“On / Off” is optional. When it is set to “On” , when the quantitative process is over or under, the instrument pauses and waits for the user to process . The digital input is stopped urgently, returns to the stop state, and the alarm is cleared; or the digital input clear alarm can clear the alarm and continue the quantitative process.
	3. Excess Under the alarm timedifference	Without manually clear the alarm, the alarmtime difference over under its own alarm off. Initial value: 1.0 ; range: 0.0 to 9. 9.9 . (units)
	4 ultradifference	In the process of quantification, if the weighing value \geq the target value + the excess value, it is judged to be excessive. Initial value: 0 .
	5. owe the difference	In the process of quantification, if the weighing value \leq target value - under-difference, it is judged as poor. Initial value: 0 .
	6. Fed under differentials switch	Set the underfeed correction judgment switch. On: Slowly add the feed according to the

		number of feeds. Off: Do not replenish when there is a shortfall.
	7. The maximum number of times due to poor feeding	When the quantitative process is judged to be inferior, the feed is slowly added according to this value. Initial value: 1 ; range 1~99 .
	8. Less effective feeding time difference	When feeding the output, the effective time is added slowly during an on-off cycle . Initial value : 0.5 ; range: 0.0 to 99.9 . (units)
	9. Invalid due to poor feeding time	When feeding an output, a pass off the cycle time has no effect on chronic . Initial value : 0.5 ; range: 0.0 to 99.9 . (units)
Drop correction parameter	Used to set relevant parameters for automatic adjustment of drop difference	
	1. Fall correction switch	The drop value is the weight value that has not fallen into the measuring hopper after the slow plus signal is turned off. The drop correction is corrected according to the actual blanking value as required. (Note: If the drop correction and adaptive functions are turned on at the same time, the drop correction function is invalid)
	2. fall correction sampling times	The meter averages the difference of the set number of times as the basis for the drop correction. Initial value: 1 ; Range: 1 to 99 .
	3. fall correction range	When the current drop value exceeds the set range, the drop will not be counted in the arithmetic mean range. Initial value: 2.0 ; Range: 0.0 to 9.9 (% of target value) .
	4. fall correction magnitude	The magnitude of each drop correction. Three ranges are available in 100% , 50% , and 25% . Initial value: 50 % .
Slow plus jog parameters	Used to set manual slow feeding related parameters	
	1. Slow add switch	“ On / Off ” is optional. When set to “On” , the meter is slowly added and jogged. Initial value: off.

	2. Inching slowly addeffective time	When the jog output is slowly added, the effective time is added slowly during an on-off cycle . Initial value : 0.5 ; range: 0.0 to 9.9 . (unit s)
	3. Slow plusjogging inactive time	When the jog output is slowly added, the inactive period is slowly added during an on-off period . Initial value : 0.5 ; range: 0.0 to 9.9 . (unit s)
Bucket scaleparameter	Used to set the relevant parameters of the bucket scale mode	
	1. Single scalecombination number	When there is a bucket scale structure , the loose bag is unloaded several times. If it is 0 , the meter discharges directly after the feeding is completed without judging whether the pocket is valid. Initial value : 1 ; Range: 0 to 99 .
No bucket scaleparameters	Used to set parameters related to the bucketless scale mode	
	1. Re-pocketdelay start time	Effective interlocking mode without fighting, A scale B when the front end of the conveyorscale after the rear end of the conveyor, and the double scale bulk bags is not the same model as loose bags . If the addition is complete loose bags B scale, the scale is not loose bags A, B scale case again a bag clip, to wait after the completion of the addition A loose scale bags, and after starting the conveyor, after which time delay before scale B start feeding. Initial value: 4.0 ; range: 0.0 to 99.9 . (unit s) (Note: This parameter is only valid when the bag is not at the same time.)
PLC parameters	Used to set PLC mode related parameters	
	1. PLC- ultra difference	When the weighing value > target value + excess value, the out-of-tolerance output is valid Initial value: 0.00 ; range: 0.00~100.00 .
	2. PLC- owe the difference	When the weighing value < target value - under-difference, the under-output is

		valid Initial value: 0.00 ; range: 0.00~100.00 .
	3. The upper limit PLC-	When the weighing value > upper limit value, the upper limit output is valid Initial value: 0.00 ; range: 0.00~100.00 .
	4. PLC- lower limit	When the weighing value is < lower limit, the lower limit output is valid. Initial value: 0.00 ; range: 0.00~100.00 .
Tons of packing scaleparameters	Used to set the relevant parameters of the ton package scale mode	
	1. Delaytimepunching bags	The bag delay time until the bag is completed . Initial value : 0.5 ; range: 0.0 to 9.9 . (unit s)
	2 bracketautomatic upswitch	After the hanging bag is finished, it is judged whether the bracket automatic rising switch is turned on, and waits for the manual rising bracket signal when it is not opened .
	3. The stent uplink delay time	This delay is executed after the rising signal is sent. Initial value: 5.0 ; range: 0.0 to 9.9 . (unit s)
	4. bracket downlinkdelay time	This delay is initiated after the quantitative delay has expired. Initial value: 5.0 ; range: 0.0 to 9.9 . (unit s)
	5 bracket up timeout(parameter retained)	The maximum waiting time for the metering bracket to be in position . Initial value: 5.0 ; range: 0.0 to 9.9 . (unit s)
	6. The stentdownlink timeout(parameter retained)	The maximum waiting time for the metering bracket to go down . Initial value: 5.0 ; range: 0.0 to 9.9 . (unit s)
	7. blowingtime	Blower blow output time . Initial value : 0.5 ; range: 0.0 to 9.9 . (unit s)
	8. A beltrunning time(this parameter retained)	Electric mode, when the belt A stop signal is invalid, and the loose bags, the belt running time after punching bag A runningoperation has been completed, the running time after starting the belt B . Initial value: 5.0 ; range: 0.0 to 9.9 . (unit s)
	9. Belt BRuntime(this parameter retained)	In the electric mode , when the stop signal of the belt B is invalid, the belt B stops

		running after the belt running time . Initial value: 5.0 ; range: 0.0 to 9.9 . (unit s)
Valve port scaleparameter	Used to set the valve scale mode related parameters	
	1. The time delay before the bag	The delay time before the bag is started at the same time when the loose bag starts to start . Initial value : 0.5 ; range: 0.0 to 9.9 . (unit s)
	2. bag effectivetime	The time is started after the delay timebefore the bag is lifted , and the bag signal output is valid. After the time is over, the bag signal output is invalid. Initial value : 0.5 ; range: 0.0 to 9.9 . (unit s)
	3. Push bagsDelay Time	When the loose bag start delay starts, the delay time before pushing the bag is started at the same time. Initial value : 0.5 ; range: 0.0 to 9.9 . (unit s)
	4. Push the bag effective time	The time is started after the delay timebefore pushing the bag , and the push bag signal output is valid. After the time is over, the push bag signal output is invalid . Initial value : 0.5 ; range: 0.0 to 9.9 . (unit s)

3.2 system and communication parameters

Under the system and communication parameters interface:

- ◆ Click the sub-option button to enter the corresponding parameter item to view and set the attribution parameter information.
- ◆ Press [Back] to exit the current interface and return to the previous interface.

System andcommunicationparameters	parameter	Description
Weightparameter	1. Criteria of Stability range	During the judgment time, the weight change range is within this set value and the meter judges that the scale is stable. Initial value: 2 ; Range: 0 to 99 (d) .
	2. Criteria of Stability time	First value: 0.3 ; range: 0.1 to 99 .
	3. Clear range	The range can be cleared . Initial value: 50 ; Range: 1 to 99 (% of full

		scale) .
	3. Zero trackingrange	The weight value is within this range and the meter is automatically cleared.When it is 0 , zero tracking is not performed. Initial value: 0 ; range: 0 to 9 (d) .
	5. Zero TimeTracking	First Value: 20; range: 0.1-9 9.9. (unit s)
	6. A / Dsampling rate	A/D sampling rate. 120 times / sec, 240 times / sec, 480times / sec, 960 times / sec. Initial value: 480 times / sec.
Filteringparameter	1 . Stop filteringlevel	Filter strength rating in the stopped state. Initial value : 7 ; range 0 ~ 9 .
	2. Secondary filter switch	On/off optional, secondary filtering based on digital filtering. Initial value: off.
	3. Dynamic filter switch	During the packaging process, whether to perform the filter operation switch and set “On” , the following three parameters are valid.
	4. Filter feed grade	Filter parameters during feeding: 9 : The filtering effect is the strongest. Initial value: 2 ; Range: 0 to 9 .
	5 level filter setting	Filter parameters during the setting process: 9 : The filtering effect is the strongest. Initial value: 7 ; Range: 0 to 9 .
	6. Unloading smoothing grade	Filter parameters during unloading: 9 : The filtering effect is the strongest. Initial value: 1 ; Range: 0 to 9 .
Functionalparameter	1. The power-on clear switch	On / off is optional. When it is “on” , the instrument will automatically perform the clear operation when the power is turned on (the weight inside the scale bucket meets the clearing range). Initial value: off
	2. Theinterval is automatically cleared	Clear the number of times after completing the packaging process. When entering the first packaging process in the running state, the meter is not cleared. Initial value: 0 ; Range: 0 to 99 . (Note: This parameter is valid only for the metering hopper packaging mode.)
	3. Run sentenced	Initial value: 0.0 ; range: 0 .0 ~ 9 9.9 .(unit s)

	stabletimeout	
	4. setting mode	<p>Stable value: After the slow feed is turned off, the weight is stabilized and the set value process is completed.</p> <p>Delay setting: After the slow feeding is turned off, the fixed value is completed after the fixed value is maintained.</p> <p>Initial value: a stable value.</p>
	5. Accumulated discharge switch manually	On/Off is optional; set to “On”, the manual unloading weight value is included in the accumulated value; initial value : off .
	6. Wt hold switch setting	<p>On/Off is optional; set to “On”, the weight display remains unchanged after the end of the set time, and the weight changes again after the discharge starts.</p> <p>Initial value : off.</p>
	7. Adaptive rating	<p>The higher the grade , the faster the feed rate and the lower the accuracy.</p> <p>Initial value: 3 ; Range: 1 to 5 .</p>
	8 adaptive switch	<p>Adaptive function, before touching the amount of slow and fast cut-off determination time during the operation of the automatic adjustment when switching on the instrument.</p> <p>Optional off , double speed, three speed.</p> <p>Initial value: off .</p> <p>(note:</p> <ol style="list-style-type: none"> 1. All advances must be zero in order to be used normally. 2. If the drop correction and the adaptive function are turned on at the same time, the drop correction function is forcibly turned off. 3. When the first scale is adaptively started, the scale body must be stable and the current weight is zero.
Scale body structure	1. scale structure	<p>There are bucket packaging / no bucket / PLC / ton bag / valve port packaging available.</p> <p>Initial value: There is a bucket packaging.</p>
	2 operating modes	<p>Optional single scale , interlock A, interlock B.</p> <p>Initial value : single scale .</p>
	3. Packing mode	The net weight packaging mode first removes the tare weight at the beginning of the quantification and performs the quantitative

		<p>packaging process with the net weight value.(effective in non-fighting mode)</p> <p>Gross weight packaging / net weight packaging is optional .</p> <p>Initial value: net weight packaging .</p>
	4. Themovement ofthe carriageway	<p>Available in pneumatic and electric .</p> <p>Initial value : pneumatic . (not changeable)</p>
	5. feedingmethods	<p>Optional separate feeding and combined feeding.</p> <p>Initial value : combined feeding.</p>
	6. Dual modescales loose bags	<p>In the bucketless interlock mode, the loose bag mode is optional:</p> <p>Not loose at the same time;</p> <p>At the same time loose bag 1 ;</p> <p>At the same time loose bag 2 .</p> <p>Initial value: no loose bags at the same time .</p> <p>Loose bags are not simultaneously;after completion of loose packing bags,to be A / B Scale all loose bags, the meter control signal output conveyor,the conveyor starts.</p> <p>At the same time, the loose bag 1: for the normal mode, the scale has been fed, and the other scale has not been fed yet. After the other scale is completed, the two scales are loose at the same time.</p> <p>If one scale has been fed and the other scale is not in the bag (feeding) state, then the other scale is not waiting, and the scale is directly loose.</p> <p>At the same time loose bag 2: for the quick mode in this mode, the default A scale is in the front B scale . Thecompletion of the A scale feeding will not judge whether B is completed or not, and directly loose the bag.</p> <p>After the B feeding is completed, it is judged whether A is in the state of the bag (feeding): if A is feeding, B should wait for the A to be added and then loose the bag; if A is not feeding, B does not need to wait for the loose bag.</p>
Serial port 485	1. Slave No.	Initial value: 1 ; 1 ~ 9 9 optional.
	2.Communication	Initial value: Modbus-RTU . Modbus-RTU/ Print / Continuous Mode / MD-R (compatible

		with 01. version) is optional.
	3. Baud Rate	Initial value: 38400 ; 9600/19200/38400/57600/115200 optional.
	4. Data Format	Initial value: 8-E-1 (8 -bit data bit -even parity - 1 stop bit) ; 8-E-1/8-N-1/7-E-1/7-N-1 is optional.
	5. Modbuslevel word	Modbus communication display mode: Initial value: AB-CD (high word first); AB-CD (high word first) / CD-AB (low word first) optional.
Serial port 232	1. Slave No.	Initial value: 1 ; 1 ~ 9 9 optional.
	2.Communication	Initial value: Modbus-RTU . Modbus-RTU / Print / Continuous Mode / MD-R (compatible with version 01.) is optional.
	3. Baud Rate	Initial value: 38400 ; 9600/19200/38400/57600/115200 optional.
	4. Data Format	Initial value: 8-E-1 (8 -bit data bit -even parity - 1 stop bit) ; 8-E-1/8-N-1/7-E-1/7-N-1 is optional.
	5. Modbuslevel word	Modbus communication display mode: Initial value: AB-CD (high word first); AB-CD (high word first) / CD-AB (low word first) optional.
Network port	1.Communication	M odbus-TCP/IP , address table viewsection 5.3.3
	2. Modbuslevel word	Modbus communication display mode: Initial value: AB-CD (high word first); AB-CD (high word first) / CD-AB (low word first) optional.
	3. Port Number	Initial value : 1 ; 1 ~ 65535 optional .
	4. IP address	Initial value : 0 ; 0 ~ 255 optional .
	5 . MAC	BC.66.41.9X.XX.XX

3 .3 peripheral parameters

Under the peripheral parameter interface:

- ◆ Click the sub-option button to enter the current parameter item to view and set the attribution parameter information.
- ◆ Press [Back] to exit the current interface and return to the previous interface.

Peripheral parameter item	parameter	Description
	1. Bag knock mode	Bag mode selection;

		<p>Initial value: Do not knock the bag.</p> <p>Optional:</p> <p>There is a bucket mode: the bag is not available after the bag / set value;</p> <p>No fighting mode: Sign bag / bags after setting Sign / addition in the film bag / bags beat plus values were correctly predicted;</p> <p>T packet mode: Sign bag / bags after setting Sign / addition in the film bag / bags beat plus values were correctly predicted;</p> <p>Port mode: Sign bag / bags after setting Sign / addition in the film bag / bags beat plus values were correctly predicted;</p> <p>PLC mode: Sign bag / bags after setting Sign / addition in the film bag / bags beat plus values were correctly predicted;</p>
	2. Sign bags initial weight	<p>It is effective in the no-bucket, tonnage, and valve-mouth scale mode. When the bag is fed in the feeding mode, the current weight must be greater than or equal to the starting weight of the bag before the bag is started.</p> <p>Initial value: 0; Range: 0 ~ Maximum range.</p>
	3. In addition the bag beat frequency	<p>Set the parameters for the number of knock in the feed. If set to 0, the bag will not be taken. Note: When the feeding process enters the slow addition, the bag is forcibly ended in the feeding, regardless of whether the bag in the feeding is completed. (Do not take the bag during the feeding after entering the small shot)</p> <p>Initial value: 0; Range: 0~99.</p>
	4. After setting the number of knock bags	<p>After the fixed value, the number of times the bag is set, the number of times the bag is taken.</p> <p>Initial value: 4; Range: 0~99.</p>
	5 knock front pocket delay	<p>After the bag is started, the bag output is valid after this delay time.</p> <p>Initial value : 0.5 ; Range : 0.0~99.9 . (units)</p>

	6 knock Bag effective time	During the on-off cycle of the bag, the bag output valid time. Initial value: 0.5 ; Range: 0.0~99.9 . (unit s)
	7. knock bags invalid time	In the on-off cycle of the bag, the bag output invalid time. Initial value: 0.5 ; Range : 0.0~99.9 . (unit s)
	8.Additionaloutput valid time to knock bags	Generally used in the anchor bag function. (Note: Extra shot bag is invalid in PLCmode) After all the bags are finished, the additional bag output is added once, and the effective time is set to the time. The invalid time is “the bag invalid time” . Initial value: 0.0 . Range : 0.0~99.9 . (units) (Note: the time when the loose bag is delayed is not changed, or the “lead bag delay” time is started after all the original bag output ends effectively , that is, the effective time of the extra bag output is started after the bag output valid time is over. To achieve the abutment function, the time and the “loose bag delay” time should be set appropriately, but the time setting shouldgenerally be greater than the “loose bag delay” , that is, the bag should be loosened first, then the bag mechanism will rise again) .
Code parameter	1. a code switch	On/off optional; set to “on” , the meter has a code output function; Initial value : off.
	2. Start coding delay	The pocket is completed, and the output is valid after the delay; Initial value: 0.5 ; Range: 0.0~99.9 . (units)
	3. Coding effective time	The effective time of coding; Initial value: 0.5 ; Range: 0.0~99.9 . (units)
	4 shall not be allowed / unloading switch coding	On/Off is optional; set to “On” , it is not allowed to start feeding (no bucket mode) output or unloading (with bucket mode)

		output during coding . Initial value : off.
Conveyor parameters	1. Conveyor switch	On/off optional; set to “on” , the meter has a conveyor output function; Initial value : off. The no-bucket mode is valid.
	2. Conveyor start-up delay	After the delay of the loose bag, the meter judges that the conveyor is started. Initial value: 0.5 ; range: 0~99.9 . (unit s)
	3. The conveyor running time	Conveyor runtime setting. Initial value: 4.0 ; range: 0~99.9 . (unit s)
Print parameters	1. Automatic print switch	On/Off is optional; when “ On ” is selected, the package result will be printed out automatically every time the package is completed (the serial port should be selected as “Print”). Initial value: off.
	2. Print format	Initial value: 24 columns of printing ; 24 columns of printing / 32 columns of printing.
	3. Print language	Initial value: Chinese ; Chinese / English optional.
	4. Print the number of lines	The number of lines after the print is completed. Initial value: 3 ; 0~9 optional.
Sewing machine	1. The sewing machine start-up delay	After the sewing machine start switch is activated, the sewing machine delay time is started . Initial value: 0.5 . Range: 0.0~99.9 . (unit s)
	2. The sewing machine output time	After the delay time has elapsed, the sewing machine output is started and the sewing machine output time is continuously output . Initial value: 4.0 . Range: 0.0~99.9 . (unit s)
	3. Tangent output time	After the sewing machine output time is over, the thread trimmer output is started and the cutter output time is continued. Initial value: 0.5 . Range: 0.0~99.9 . (unit s)
	4. The sewing machine	After the work is completed and cutting

	stop delay	<p>machine, sewing machine continues to work, sewing machine stop delay time after up to stop.</p> <p>Initial value: 0.5 . Range: 0.0~99.9 . (unit s)</p>
Unloadingrapping parameter	1. Open the discharge rap (knock)	Initial value : 0 ; range 0~1 . (0 : open; 1 : off)
	2. The effective discharge time	<p>When the fixed value is maintained, the discharge effective time is from the time when the discharge signal is output to the time when the discharge is completed and the discharge delay is started. If the discharge time exceeds this time, it is considered abnormal, and the discharge rapping action is started.</p> <p>Initial value : 2.0 ; range 0.0~9.9 . (unit s)</p>
	3. Discharge rapping effective time	Initial value : 0.5 ; range 0.0~9.9 . (unit s).
	4. Discharge rapping ineffective time	Initial value : 0.5 ; range 0.0~9.9 . (unit s)
	5. Discharge rapping times	Initial value : 10 ; range 0 ~ 99 .
Adding and discharging timeout judgment	1. Timeout detection switch	<p>Add and discharge timeout judgment switch. After the opening , the loading and unloading timeout judgment is performed in the running state .</p> <p>Initial value : off .</p>
	2 Fast time feeding overtime	<p>In the running state, after the fast output exceeds the time, the output timeout alarm is issued and the machine stops.</p> <p>Initial value : 5.0 ; range 0.0~99.9 . (units)</p>
	3. Medium feeding timeout	<p>In the running state, after the output is over this time, the output timeout alarm is issued and the machine stops.</p> <p>Initial value : 5.0 ; range 0.0~99.9 . (units)</p>
	4. Slow feeding timeout	<p>In the running state, after the slow output exceeds the time, the output timeout alarm is issued and the machine stops.</p> <p>Initial value : 5.0 ; range : 0.0~99.9 .(unit s)</p>
	5. Discharge time out	In the running state, after the discharge output exceeds this time, the output

		<p>timeout alarm and stop.</p> <p>Initial value : 5.0 ; range : 0.0~99.9 .(unit s)</p>
Auxiliary pulse parameter	1. The auxiliary pulse 1 total execution time	<p>Auxiliary pulse 1 performs the total time. If it is 0, it will be executed all the time.</p> <p>Initial value : 0 ; range : 0.0~999.9 .(unit s)</p>
	2. 1 effective auxiliary pulse time	<p>Initial value : 10.0 ; range : 0.0~999.9 .(unit s)</p>
	3. The auxiliary pulse 1 invalid time	<p>Initial value : 10.0 ; range : 0.0~999.9 .(unit s)</p>
	4. The total run time of the auxiliary pulse 2	<p>Auxiliary pulse 2 performs the total time. If it is 0, it will be executed all the time.</p> <p>Initial value : 0 ; range : 0.0~999.9 .(unit s)</p>
	5. 2 auxiliary pulse effective time	<p>Initial value : 10.0 ; range : 0.0~999.9 .(unit s)</p>
	6. Invalid auxiliary pulse time 2	<p>Initial value : 10.0 ; range : 0.0~999.9 .(unit s)</p>
	7. The total run time of the auxiliary pulse 3	<p>The auxiliary pulse 3 performs the total time. If it is 0, it will be executed all the time.</p> <p>Initial value : 0 ; range : 0.0~999.9 .(unit min)</p>
	8. 3 the auxiliary pulse effective time	<p>Initial value : 10.0 ; range : 0.0~999.9 .(unit min)</p>
	9. invalid auxiliary pulse 3 times	<p>Initial value : 10.0 ; range : 0.0~999.9 .(unit min)</p>
	10. The total run time of the auxiliary pulse 4	<p>The auxiliary pulse 4 performs the total time. If it is 0, it will be executed all the time.</p> <p>Initial value : 0 ; range : 0.0~999.9 .(unit min)</p>
	11. 4 auxiliary pulses effective time	<p>Initial value : 10.0 ; range : 0.0~999.9 .(unit min)</p>
	12. The dead time of the auxiliary pulse 4	<p>Initial value : 10.0 ; range : 0.0~999.9 .(unit min)</p>

3.4 motor parameters

Under the motor parameter interface:

- ◆ Click the sub-option button to enter the current parameter item to view and set the attribution parameter information.
- ◆ Press [Back] to exit the current interface and return to the previous interface.

Motor parameter item	parameter	Description
Motor parameters	1. Formula number	The recipe currently in use. Initial value: 1 ; Range: 1~20 .
	2. Motor group number used in the current recipe	The feed motor group number corresponding to the current recipe. Initial value: 0 , range 0~4 .
Feeding parameter	1. Feed mode	Initial value: pneumatic feeding; Optional: 0 , pneumatic mode; 1 , stepper motor feeding; 2 , ordinary motor mode.
	2. Feeding door closing timeout	Initial value: 4.0 ; range: 0.0~99.9 .
	3. Feeding door closes in place signal type	Initial value: 0 ; Type optional : 0 : The signal is in place when it is valid; 1 : When the signal is invalid , it is in place .
	4. Feeding motor group number	Initial value: 0 ; Range: 0~4 Feeding motor group number setting.
	5. Feeding motor frequency	Initial value: 12000 ; range: 1~50000 .
	6. Close to slow increase the number of pulses required	Initial value: 1800 ; Range: 1~60000 .
	7. Close the number of pulses required to add	Initial value: 4300 ; range: 1~60000 .
	8. Close to fast increase the number of pulses required	Initial value: 7750 ; range: 1~60000 .
	9. Adding door opening direction signal status	Feeding door opening motor rotation direction signal state Initial value: when the signal is invalid, it is the direction of opening the door;

		<p>Optional:</p> <p>When the 0 signal is invalid, the door opening direction is: when the feeding door is opened, the signal output of the feeding stepping motor is invalid, and the direction signal output is valid when the door is closed.</p> <p>A valid signal to the door opening direction: door open when loading operation, the rotation direction of the stepping motor to feed the signal output valid signal is output when the closing operation direction invalid.</p>
	10. Feed motor starting frequency	<p>Feed motor starting frequency</p> <p>Initial value: 2000 ; Range: 0~50000 .</p> <p>(Note: this value cannot be greater than the feeding motor frequency)</p>
	11. Feed motor acceleration time	<p>Feed motor acceleration time (in ms)</p> <p>Initial value: 200 ; range: 0~9999 .</p>
	12. Feed motor deceleration time	<p>Feed motor deceleration time (in ms)</p> <p>Initial value: 50 ; range: 0~9999 .</p>
	13. Quickly open the door	<p>The time it takes for the loading door to open to the quick-add (fast-add) position.</p> <p>Initial value: 0.8 0 ; Range: 0~99 . 99 .(unit s)</p>
	14. China and Canada opening time	<p>The time it takes for the feed door to open to the middle (plus) position.</p> <p>Initial value: 0.4 0 ; Range: 0 . ~99.99 .(unit s)</p>
	15. Slow opening time	<p>The time it takes for the feed door to open to the slow (slow plus) position.</p> <p>Initial value: 0.2 0 ; Range: 0~99.99 . (units)</p>
Clip loose bag parameters	1 , pocket mode	<p>Initial value: 0 , pneumatic clamp loose bag ;</p> <p>Optional:</p> <p>0 , pneumatic clip loose bag;</p> <p>1 , stepper motor clip loose bag;</p> <p>2 , motor double limit clip loose bag;</p> <p>3 , motor single limit clip loose bag.</p>
	2 , loose bag process timeout	<p>Initial value: 3.0 ; range: 0.0~99.9 . (unit s)</p>
	3 , the bagging process timeout	<p>Initial value: 3.0 ; range: 0.0~99.9 . (unit s)</p>
	4 , loose bag in place signal status	<p>Initial value: 0 ;</p> <p>Optional:</p> <p>0 : The signal is in place when it is valid;</p>

		1 : When the signal is invalid, it is in place .
	5 , pocket motor frequency	Initial value: 30000 ; range: 1~50000 .
	6 , loose bag motor frequency	Initial value: 20000 ; range: 1~50000 .
	7 , the number of pulses required to pocket	Initial value: 12000 ; range: 1~60000 .
	8 , the motor direction signal statefolder bag	Initial value: 0 ; Optional: 0 : the entrainment direction when the signal is invalid ; 1 : Entrainment direction when the signal is valid .
	9 , the pocket motor starting frequency	Initial value: 2000 . (Note: this value cannot be greater than the pocket frequency)
	10 , pocket motor acceleration time	Initial value: 200 ; range: 0.0~99.99 . (unit m s)
	11 , bag motor deceleration time	Initial value: 50 ; Range: 0.0~99.99 . (unit m s)
Discharge parameter	12 , loose bag effective time	Initial value: 0.5 ; range: 0.0~99.99 . (units)
	1 , unloading mode	Initial value: 0 pneumatic discharge; Optional: 0 : pneumatic mode ; 1 : Stepping motor unloading; 2 : motor single limit discharge; 3 : motor double limit discharge; 4 : The motor rotates in one direction.
	2 , discharge closing timeout time	Initial value : 3.0 ; range: 0.0~99.9 . (units)
	3 , discharge opening timeout time	Initial value : 3.0 ; range: 0.0~99.9 . (units)
	4 , discharge in place signal type	Initial value: 0 ; Optional: 0 : The signal is in place when it is valid;

		1 : When the signal is invalid, it is in place .
	5 , discharge limit real-time detection switch	On/off is optional; when "On" is selected, the limit signal is detected in real time; when "Off", the limit signal is detected only when the feed is started . Initial value: off.
	6 , discharge door opening motor frequency	Initial value : 30000 ; range: 1~50000 .
	7 , discharge closing motor frequency	Initial value : 20000 ; range: 1~500 00 .
	8 , the number of pulses required for unloading	Initial value : 12000 ; range: 1~60000 .
	9 , the discharge direction signal status	Initial value: 0 ; Optional: 0 : the door opening direction when the signal is invalid ; 1 : valid signal to the door opening direction.
	10 , discharge motor starting frequency	Initial value: 2000 ; range: 0~50000 . (Note: this value cannot be greater than the discharge frequency)
	11 , the discharge motor acceleration time	Initial value: 200 ; range: 0.0~99.99 . (in ms)
	12 , unloading motor deceleration time	Initial value: 50 ; range: 0.0~99 . 99 . (in ms)
	13 , discharge opening time output time	Initial value : 1.00 ; range : 0.00~99.99 .(unit s)

3.5 calibration

The calibration scale is the calibration of the instrument. When the **GM9907** packaging controller or any part of the weighing system is changed for the first time and the current equipment calibration parameters cannot meet the user's requirements, the controller should be calibrated. The calibration scale parameter directly affects the weighing result of the instrument. To prevent personnel from mis operation, the administrator and the system administrator are required to log in to calibrate the instrument (select the identity login in the [User Login] option).

The calibration scale parameter of the national standard symmetrical heavy instrument requires password protection. Therefore, the

password must be entered correctly when entering the calibration parameters (initial password: **000000**); the calibration password is changed in the “Password Management” item of [System Information]. .

Under the calibration scale interface:

- ◆ Click the sub-option button to enter the current parameter item to view and set the attribution parameter information.
- ◆ Press [Back] to exit the current interface and return to the previous interface.

Calibration scale parameter	School child scale	Description	
Weighing parameter	1 unit	Initial value: kg ; g/kg/t/lb is available.	
	2. Decimal point	. Initial value: 000; 0 to 0.0000 five kinds of options.	
	3. Minimum division	Initial value: 1 ; 1/2/5/10/20/50 six optional .	
	4. Maximum range	Initial value: 100.00 ; The range is less than or equal to the minimum division $\times 10\ 0000$ can be set .	
Empty scale calibration	Current weight	Display current weighing platform weight value	In this interface, after clearing the weighing platform (scale bucket) is stable, press the [empty scale calibration] button to calibrate the current state to zero.
	Current voltage value	Display current sensor output voltage value	
Weight calibration scale	Current weight	Display current weight value	In this interface, load the weight on the weighing platform (weighing bucket). After stabilization, press [Gain Calibration] to pop up the dialog box, enter the weight value of the weight, and complete the calibration of the weight value of the instrument.
	Gain voltage value	Display load weight output voltage value	

3.6 Cumulative and batch

- ◆ Click the sub-option button to enter the current parameter item to view and set the attribution parameter information.
- ◆ Press [Back] to exit the current interface and return to the previous interface.
- ◆ Under the “Total Accumulation and Batch” parameter, the user can view the total accumulated value and accumulated times under the formula, and clear and print the accumulated.
- ◆ Click [Clear Total Accumulation] on the “Total Accumulation and Batch” interface, enter the clear accumulated password to delete the total accumulated and all formula accumulations and all user accumulates.
- ◆ Click [Clear All Receipts] on the “Recipe Accumulation” interface , and enter the clear accumulated password to delete all recipes.
- ◆ Click [Clear All Users Accumulate] on the "User Accumulation" interface, and enter the clear accumulated password to delete

all user accumulates.

- ◆ Click the formula to be deleted in the formula accumulation interface, and enter the clear accumulated password to delete the accumulated content of the selected formula.
- ◆ In the user cumulative interface, click on the user to be deleted, and enter the clear accumulated password to delete the accumulated content of the selected user.
- ◆ If the serial port is set to print, according to a corresponding cumulative total cumulative interface [Print], [print selected recipe total], [all recipes accumulated print], [print] accumulated selected users, all users [print] accumulated; if No serial port is set to print. Pressing the above button on the corresponding cumulative interface will prompt “No serial port is set to print mode and cannot be printed”
- ◆ In total cumulative batch to batch interface provided [] set the number of batches, such as when the number of batches completed set, playing the instrument in the main interface box prompts "**batch to complete**" alarm and shutdown, the processing waits for the user, then Make the "clear alarm" input signal valid, or click the "clear alarm" button to clear the above alarm, or enter the emergency stop to return to the stop state.

Note : If you work in combination mode , the batch count counter is incremented by **1** **when the** number of combinations is completed . The set number of batches and the accumulated batch number are saved after power down .

3.7 switching

The GM9907 provides **12** inputs and **16** output interfaces to interface the instrument with external devices.

The input and output factory definition contents are as follows (output **1 - 16** corresponds to the instrument **OUT1 ~ OUT16** interface, input **1 - 12** corresponds to the instrument **IN1 ~ 12** interface).

There are hopper scales default definition:

Output		Input quantity	
Output port -1	O1 running	Input port - 1	I1 start
Output port -2	O2 stop	Input port - 2	I2 emergency stop
Output port -3	O3 fast	Input port - 3	I3 slow stop
Output port -4	O4 Canada	Input port - 4	I5 clear
Output port -5	O5 slow plus	Input port - 5	I6 clear alarm
Output port -6	O6 pocket	Input port - 6	I8 total accumulated
Output port -7	O7 setting	Input port - 7	I7 clip loose bag request
Output port -8	O8 scales are good	Input port - 8	I9 manual unloading
Output port -9	O9 unloading	Input port - 9	I10 manual slow addition
Output port -10	O10 zone	Input port - 10	I11 manual fast
Output port -11	O11 shot bag	Input port - 11	I13 formula
Output port -12	O13 feeding	Input port - 12	I12 clearing material
Output port -13	O14 lack of material	Note: In interlock mode. Input port -12 is the interlock input. Output port -16 is the dual scale interlock output.	
Output port -14	O15 alarm		
Output port -15	O17 batch completed		
Output port -16	O16 super poor		

Without hopper scale default definition:

Output		Input quantity	
Output port -1	O1 running	Input port - 1	I1 start
Output port -2	O2 stop	Input port - 2	I2 emergency stop
Output port -3	O3 fast	Input port - 3	I3 slow stop
Output port -4	O4 Canada	Input port - 4	I4 suspended
Output port -5	O5 slow plus	Input port - 5	I5 clear
Output port -6	O6 pocket	Input port - 6	I6 clear alarm
Output port -7	O7 setting	Input port - 7	I8 total accumulated
Output port -8	O10 zone	Input port - 8	I7 clip loose bag request
Output port -9	O11 shot bag	Input port - 9	I10 manual slow addition
Output port -10	O15 alarm	Input port - 10	I11 manual fast
Output port -11	O13 feeding	Input port - 11	I13 formula
Output port -12	O27 loose bag	Input port - 12	I12 no definition
Output port -13	O14 lack of material	Note: In interlock mode. Input port -12 is changed to interlock input . Output port -12 is changed to missing material. Output port- 13 is changed to batch completion. Output port- 14 is changed to the sewing machine output. Output port -15 is changed to conveyor output. Output port- 16 is changed to dual scale interlock output.	
Output port -14	O17 batch completed		
Output port -15	O16 super poor		
Output port -16	O44 sewing machine output		

P LC mode default definition:

Output		Input quantity	
Output port -1	O3 fast	Input port - 1	I5 clear
Output port -2	O4 Canada	Input port - 2	I6 clear alarm
Output port -3	O5 slow plus	Input port - 3	No definition
Output port -4	O38 tolerance (PLC)	Input port - 4	No definition
Output port -5	O39 poor (PLC)	Input port - 5	No definition
Output port -6	O49 upper limit	Input port - 6	No definition
Output port -7	Lower limit of O41	Input port - 7	No definition
Output port -8	No definition	Input port - 8	No definition
Output port -9	No definition	Input port - 9	No definition
Output port -10	No definition	Input port - 10	No definition

Output port -11	No definition	Input port - 11	No definition
Output port -12	No definition	Input port - 12	No definition
Output port -13	No definition		
Output port -14	No definition		
Output port -15	No definition		
Output port -16	No definition		

Ton scales default definition:

Output		Input quantity	
Output port -1	O1 running	Input port - 1	I1 start
Output port -2	O2 stop	Input port - 2	I2 emergency stop
Output port -3	O3 fast	Input port - 3	I3 slow stop
Output port -4	O4 Canada	Input port - 4	I4 suspended
Output port -5	O5 slow plus	Input port - 5	I5 clear
Output port -6	O6 pocket	Input port - 6	I6 clear alarm
Output port -7	O31 hanging bag	Input port - 7	I8 total accumulated
Output port -8	O3 measuring bracket uplink	Input port - 8	I7 clip loose bag request
Output port -9	O7 setting	Input port - 9	I32 bag request
Output port -10	O10 zone	Input port - 10	I3 manual control bracket up / down
Output port -11	O33 return valve	Input port - 11	I19 manual slow addition
Output port -12	O32 blowing	Input port - 12	I20 manual fast
Output port -13	O15 alarm		
Output port -14	O17 batch completed		
Output port -15	No definition		
Output port -16	No definition		

The valve port scale is defined by default:

Output		Input quantity	
Output port -1	O1 running	Input port - 1	I1 start
Output port -2	O2 stop	Input port - 2	I2 emergency stop
Output port -3	O3 fast	Input port - 3	I3 slow stop
Output port -4	O4 Canada	Input port - 4	I4 suspended
Output port -5	O5 slow plus	Input port - 5	I5 clear
Output port -6	O6 pocket	Input port - 6	I6 clear alarm
Output port -7	O 7 setting	Input port - 7	I8 total accumulated
Output port -8	O17 batch completed	Input port - 8	I7 clip loose bag request

Output port -9	O10 zone	Input port - 9	I10 manual slow addition
Output port -10	O11 shot bag	Input port - 10	I11 manual fast
Output port -11	O13 feeding	Input port - 11	I13 formula
Output port -12	O15 alarm	Input port - 12	I12 no definition
Output port -13	O16 super poor		
Output port -14	O30 push bag signal		
Output port -15	O29 bag signal		
Output port -16	No definition		

3.7.1 Output, input port definition

The output port and input port contents can be defined according to the actual application. Under the switch interface:

- ◆ Click the sub-option button to enter the current parameter item to view and set the attribution parameter information.
- ◆ Press [Back] to exit the current interface and return to the previous interface.

Switch content description

Output		
Code	content	Description
O0	No definition	If the port number is defined as 0 , this output port is undefined.
O1	run	When the meter is in the running state, the output port signal is valid.
O2	stop	When the meter is in the stop state, the output port signal is valid.
O3	Quick add	Used to control the large discharge port of the feeding mechanism. During the feeding process, when the current weight is less than the target value -faster advance amount, the output port signal is defined as valid.
O4	China and Canada	Used to control the middle discharge port of the feeding mechanism. During the addition, the current weight is less than the target value - added inadvance during the definition output signal is active.
O5	Slow plus	Used to control the small discharge port of the feeding mechanism. During the feeding process, when the current weight is less than the target value -fall difference, the output port signal is defined as valid.
O6	Pocket	It is used to control the pocket mechanism, and the signal effectively realizes the pocket; the signal is invalid, that is, the loose bag.
O7	Value	Used to indicate the end of the feeding process. The output port signal is valid before the end of the slow addition to the discharge (with bucket) or the bag (no bucket).
O8	Weigh	After the setting is completed, the output port signal is valid.
O9	Unloading	A discharge door for controlling the measuring bucket. The defined output port signal is valid when the discharge is started, so that the material is discharged from the measuring bucket into the package.
O10	Zero zone	When the current weight of the scale is less than the set near zero value, the output port signal is valid.
O11	Shooting bag	Used to control the bag making machine. A pulse signal with a controlled pulse width and number of times.

O12	Cutting	This output is valid during the feed and is not valid during the non-feed period .
O13	supply	The feeding mechanism for controlling the front end of the packaging scale, when the feeding hopper lower level input (the lower material level input is defined) is invalid, the output is valid; when the feeding hopper upper material level (the loading level input is defined) is valid, The meter invalidates this output.
O14	Missing material	When the blanking input is defined and the input is invalid, the output is valid. When the hopper lowering level (the lowering input is defined) is valid, the meter invalidates the output.
O15	Call the police	When the meter has an out-of-tolerance, batch number, etc. alarm, the output port signal is valid.
O16	Super poor	When the tolerance or undershoot is exceeded, the output signal is defined as valid.
O17	Batch completion	When the set number of batches is completed, the output port signal is valid.
O18	Double scale interlock output	Used in the double scale mode, connected to the switch “Double scale interlock input” of another meter.
O19	Feed pulse output	When the feeding mode is set to stepper motor mode to control the feeding door switch: This signal is used as a pulse signal output to the feeding stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the ports of OUT12~16 .
O20	Feeding direction signal	When the feeding mode is set to stepper motor mode to control the feeding door switch: This signal is used as the motor rotation direction signal output to the feeding stepping motor driver to control the motor to reverse. Note: This function can only be defined on one output port. There can be no multiple output ports to define this function. And can only be defined to one of the ports OUT1~11 .
O21	Pinch bag pulse output	When the bag mode is set to the stepping motor mode control clip loose bag: This signal is used as the output pulse signal to the pinch stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the ports of OUT12~16 .
O22	Clip pocket direction signal	When the bag mode is set to the stepping motor mode control clip loose bag: This signal is used as the motor

		<p>rotation direction signal output to the pinch bag stepping motor driver to control the motor to reverse. (No bucket mode is valid)</p> <p>Note: This function can only be defined on one output port. There can be no multiple output ports to define this function. And can only be defined to one of the ports OUT1~11 .</p>
O23	Discharge output pulse	<p>When the unloading mode is set to stepper motor mode to control unloading: this signal is used as a pulse signal output to the discharge stepper motor driver to control the motor rotation.</p> <p>Note: This function can only be defined on one of the ports of OUT12~16 .</p>
O24	Discharge direction signal	<p>When the unloading mode is set to stepper motor mode to control unloading: this signal is used as the motor rotation direction signal output to the discharge stepper motor driver to control the motor to reverse.</p> <p>Note: This function can only be defined on one output port. There can be no multiple output ports to define this function. And can only be defined to one of the ports OUT1~11 .</p>
O25	Adding a door	<p>When the feeding mode is set to the normal motor mode to control the feeding door switch: the large discharging port for controlling the weighing mechanism is opened. This signal is active at the beginning of the feeding process and the effective time is set in the motor parameters.</p>
O26	Adding material closes	<p>When the feeding mode is set to the normal motor mode to control the feeding door switch: it is used to control the action of closing the feeding port of the feeding mechanism. The signals are valid at the time of fast addition, medium addition and slow addition respectively. The effective time is based on the time parameter set in the motor parameters. It is decided that the signal is valid at the end of the feed until it becomes invalid when the feed limit is valid.</p>
O27	Loose bag	<p>When the bag mode is set to the ordinary motor control clip loose bag: it is used to control the loose bag. When the signal is valid, the motor is driven to perform the loose bag action. When the signal is invalid, the loose bag action stops.</p>
O28	Discharge closing	<p>When the unloading mode is set to normal motor forward and reverse control discharge, it is used to control the closing action of the metering bucket discharge door. When the signal is valid, the motor is driven to open and</p>

		close the door. When the signal is invalid, the door closing action stops.
O29	Bag signal	It is used to control the bag-making mechanism, and this signal effectively realizes the bag-lifting action.
O30	Push bag signal	It is used to control the push bag mechanism, and the signal effectively realizes the push bag action.
O31	Hanging bag	It is used to control the bag mechanism, and the signal effectively realizes the hanging bag; the signal is invalid and the hook is loose.
O32	Blowing	For controlling the operation of the blowing means, at the end of the metering bracket upward, the signal is valid.
O33	Return valve	Return valve for controlling the run, at the end of blowing, the signal is valid.
O34	Metering bracket up (this parameter is reserved)	Used to control the upstream of the metering bracket. This signal is valid until the upper limit is valid if both the bag and the bag have been completed before feeding. This signal output is valid after the loose bag is completed. Until the lower limit input is valid.
O35	Measuring bracket down (electric) (this parameter is reserved)	Used to control the downstream of the metering bracket. (When there is a bag making function, it needs to be started after the bag is finished).
O36	Belt A (this parameter is reserved)	Electric mode, for controlling the operation of the belt A, the loose bags, the hook after the song, the signal is valid.
O37	Belt B (this parameter is reserved)	Electric mode, for controlling operation of the belt B, the belt A is stopped, the signal is valid.
O38	Out of tolerance (PLC)	This signal is valid when it is out of tolerance (PLC) .
O39	Undershoot (PLC)	This signal is valid when there is a short circuit (PLC) .
O40	Upper limit (PLC)	When the weighing value > upper limit value, the upper limit output is valid .
O41	Lower limit (PLC)	When the weighing value < lower limit, the lower limit output is valid .
O42	Conveyor conveyor	In the bucketless mode, it is used to control the start and stop of the conveyor. The signal is effectively activated by the conveyor and the signal is invalid and the conveyor is stopped.
O43	add mosaic	The code signal is output when the pocket signal output is valid and the code delay is over.
O44	Sewing machine output	When the sewing machine input is valid, the sewing machine output is valid.
O45	Tangential	After the sewing machine output time is over, the output is

	machine output	valid, and the effective time is the tangential machine output time .
O46	Auxiliary pulse output 1	After the auxiliary pulse input effective, the output pulse signal (valid for the auxiliary pulse aneffective time, dead time of the auxiliary pulse adead time), and outputs the total time to stop the output (the total time is set to 0 , it has been by Pulse output) .
O47	Auxiliary pulse output 2	After the auxiliary pulse 2 input is active, the output pulse signal (valid for the auxiliary pulse 2effective time, dead time of the auxiliary pulse 2dead time), and outputs the total time to stop the output (the total time is set to 0 , it has been by Pulse output) .
O48	Auxiliary pulse output 3	After the auxiliary pulse 3 input is valid, the pulse signal is output (the effective time is theauxiliary pulse 3 valid time, the invalid time is the auxiliary pulse 3 invalid time), and after the output execution total time is reached, the output is stopped (the total execution time is set to 0 , then the button is pressed. Pulse output) .
O49	Auxiliary pulse output 4	After the auxiliary pulse 4 input is valid, the pulse signal is output (the effective time is theauxiliary pulse 4 valid time, the invalid time is the auxiliary pulse 4 invalid time), and after the output execution total time is reached, the output is stopped (the total execution time is set to 0 , then the button is pressed. Pulse output) .
O50	Unloading rapping	The output of the discharge rapping function.
O51	Auxiliary logic output 1	Auxiliary logic 1 output signal.
O52	Auxiliary logic output 2	Auxiliary logic output signal 2 .
O53	Auxiliary logic output 3	The output signal of the auxiliary logic output 3 .
O54	Auxiliary logic output 4	The output signal of the auxiliary logic output 4 .
O55	Auxiliary logic output 5	The output signal of the auxiliary logic output 5 .
O56	Auxiliary logic output 6	The output signal of the auxiliary logic output 6 .
Input quantity		
I0	No definition	If the port number is defined as 0 , this input port is undefined.
I1	start up	The signal valid meter will enter the running state.This input

		is a pulse input signal.
I2	Emergency stop	The signal valid meter will return to the stop state. This input is a pulse input signal.
I3	Slow stop	The signal valid meter will return to the stop state after completing the current packaging process. This input is a pulse input signal.
I4	time out	The signal valid meter will suspend work, retain the current state, and resume working after receiving the start signal . This input is a pulse input signal.
I5	Clear	The signal valid meter will clear the weight. This input is a pulse input signal.
I6	Clear alarm	Used to clear the alarm output of the meter. This input is a pulse input signal.
I7	Clip loose bag request	It is used to control the action of the pocket mechanism. This input is effective for one pocket output, and the effective pocket output is invalid again (ie: loose bag).
I8	Total accumulation	Clearing the total accumulated weight and number of times will also clear the recipe accumulation and user accumulation .
I9	Manual unloading	Used to manually remove material from the measuring hopper. The input is effective once, the discharge output is valid, and the effective discharge output is invalid again.
I10	Manual slow addition	The input is valid once and the output is valid, and the effective slow input is invalid again.
I11	Manually add	Pulse type signal. Function in the stop state, used to manually turn the meter on and off. Effective once, it is effectively turned off again.
I12	Clear material	Pulse type signal. Acting in the stop state, used to empty the storage hopper while opening the discharge door and the feed door. Effective once , it is effectively turned off again. (No action in bucket, PLC, valve port, ton package mode)
I13	Selection formula	This input is valid once, the recipe number is changed to the next target whose value is not zero, and the recipe number with the target value of zero is skipped.
I14	Feed level	Used to connect the upper level of the hopper, this input should be level input.
I15	Cutting level	Used to connect the lower level of the hopper, this input should be level input. The blanking bit input is invalid or left blank to indicate the material shortage. The blanking level input is valid to indicate that there is no shortage of


		material.
I16	Start/emergency stop (level)	The signal is valid and the instrument enters the running state. If it is invalid, it returns to the stop state. This input is a level signal.
I17	Start/slow stop (level)	The signal valid instrument enters the running state, and if it is invalid, it returns to the stop state after completing the current packaging process. This input is a level signal.
I18	Manualunloading (level)	Used to manually remove material from the measuring hopper. The input effective discharge output is valid, and the input invalid discharge output is invalid.
I19	Manual slow addition (level)	The signal is effectively slow and the signal output is valid. The signal is invalid and the slow signal output is invalid.
I20	Manual quick addition (level)	The signal is valid and the signal output is valid. The signal is invalid and the signal output is invalid.
I21	Pocket in place (level)	<p>If this input is defined, it effectively indicates that the pocket is in place, and vice versa .</p> <p>No fighting mode: the folder bag has state, the instrument must be detected "bag-in place" input active material began to increase, the process of adding material, detecting whether the signal is not valid. This input should be a level input.</p>
I22	Discharge door opening door (level)	The unloading mode is set to the normal motor forward and reverse double limit mode to control the unloading: this signal is used as the limit input signal of the discharge door opening door. When the instrument detects that the signal is valid, it considers that the discharge door has been opened.
I23	Feeding door closes in place(level)	When the unloading mode is set to normal motor forward and reverse double limit mode to control unloading: this signal is used as the limit input signal of the feeding door closing door. When the instrument detects that the signal is valid, it considers that the feeding door has been closed.
I24	Discharge door closes in place(level)	This signal acts as a limit input signal for the discharge door to close the door. When the instrument detects that the signal is valid, it considers that the discharge door has been closed.
I25	Loose bag in place (level)	<p>The pocket mode is set to stepper motor clip loose bag / motor double limit clip loose bag mode control clip loose bag: This signal is used as the limit input signal of the pocket bag loose bag in place.</p> <p>(Note: This signal is determined by the type of in-position signal and is set to positive logic: when the input signal is valid, it is considered that the pocket mechanism has</p>


		been loosened in place ; set to reverse logic: when the input signal is invalid, it is considered that the pocket mechanism has been loosened in place.)
I26	Sewing machine start	When the digital input is valid, the effective output of the sewing machine is started.
I27	Sewing machine emergency stop	When the digital input is valid, the sewing machine stops outputting.
I28	Auxiliary pulse input 1	A custom trigger input signal for auxiliary logic 1 .
I29	Auxiliary pulse input 2	A custom trigger input signal for auxiliary logic 2 .
I30	Auxiliary pulse input 3	A custom trigger input signal for auxiliary logic 3 .
I31	Auxiliary pulse input 4	A custom trigger input signal for auxiliary logic 4 .
I32	Sling bag request	Used to control the movement of the bag mechanism.
I33	Stand up in place	The upper limiter for connecting the metering bracket, this input should be a pulse input .
I34	Bracket down in place	The lower limiter used to connect the metering bracket, which should be a pulse input .
I35	Bracket down limit	The lower limiter for connecting the metering bracket, this input should be a pulse input .
I36	Belt A stop input (this parameter is reserved)	In the electric mode , the stop detection sensor for connecting the belt A , which should be a pulse input .
I37	Belt B stop input (this parameter is reserved)	In the electric mode, the stop detection sensor for connecting the belt B should be a pulse input.
I38	Manual bracket up /down input	Used to control the motion of the stand, this input is a pulse input. The motion of the stand can be controlled in the stopped state. In the running state, it is the start signal of the motion of the bracket.
I39	Interlock input	Used in the double scale mode, the switch "double scale interlock output" used to connect another meter.
I40	Auxiliary output 1 logic	A custom trigger input signal for auxiliary logic 1 .
I41	Auxiliary output 2 logic	A custom trigger input signal for auxiliary logic 2 .
I42	Auxiliary output 3 logic	A custom trigger input signal for auxiliary logic 3 .
I43	Auxiliary output 4 logic	A custom trigger input signal for auxiliary logic 4 .
I44	Auxiliary output 5 logic	A custom trigger input signal for auxiliary logic 5 .

	output 5	
I45	Auxiliary output 6	logic The custom logic 6 's custom trigger input signal.

3.7 .2IO test

The user can check whether the instrument output and the input interface are connected to the external device through the **IO** test. **The IO test interface is shown below:** **Output port test** : In the **IO**test interface, the output test is started. After clicking the corresponding output port button, the interface port color is lit, and the corresponding external connection output status should be valid. If it is invalid, the connection is indicated. Abnormal, check the switching power supply input, wiring, etc. **Input test**: the test interface **IO**, when the external input signal is active, the interface corresponding to the input port defined light blue color lights. When the external input is valid, the interface does not respond, indicating that the connection is abnormal, check the switching power supply input, wiring, and so on.

7.I/O Module		
Input Test		
IN 1 Start	IN 2 Emergency Stop	IN 3 Stop
IN 4 Zeroing	IN 5 Clear Alarm	IN 6 Clear Total ACUM
IN 7 Bag Lock/Unlock Request	IN 8 Manual Discharge	IN 9 Manual Fine Flow
IN10 Manual Coarse Flow	IN11 Change Recipe	IN12 Empty Material
		Return

7.I/O Module			
Output Test			
OUT 1 Running	OUT 2 Stopped	OUT 3 Coarse Flow	OUT 4 Medium Flow
OUT 5 Fine Flow	OUT 6 Bag Lock	OUT 7 Result Waiting	OUT 8 Ready
OUT 9 Discharge	OUT10 (-NZ-)	OUT11 Pat Bag	OUT12 FILL
OUT13 EMPT	OUT14 Alarm	OUT15 Batch Complete	OUT16 Over/Under
			Return

3. 8 auxiliary logic programming

Auxiliary logic programming function, up to 6 sets of auxiliary logic trigger signals can be defined , and the effective time and output port after the auxiliary logic signal is triggered can be set. The simple logic signal output can be configured to control other

auxiliary devices, and 6 sets of auxiliary logic signals. They can also control each other.

Under the auxiliary logic programming interface:

- ◆ Click the sub-option button to enter the current parameter item to view and set the attribution parameter information.
- ◆ Press [Back] to exit the current interface and return to the previous interface.

Auxiliary logic programming parameter items 1~ 6	parameter	Description
A logic (1-6)Type	Close (default)	The type of auxiliary logic programming signal is selected based on the logic to be implemented.
	Delayed on	
	Delayed disconnection	
	Delay on time delay	
	Invalid - valid edge triggered	
	Valid-invalid edge-triggered	
2. Logical (1-6) a trigger signal	Custom trigger input (default)	After setting any of the 1~ 12 channels as the trigger signal, the input port will be fixed as the trigger signal.
	IN port 1~12	Set any of the 1~ 12 input ports as the trigger signal, then the input can be either the trigger signal or the function signal of the input port.
	Switch output definition	After the trigger signal is set to “an internal function signal” , the trigger output is performed according to the function signal.
	> = or < = weight valuetrigger	After the trigger condition is set , the current weight value is compared with the set weight threshold , and the output is triggered when the condition is met .
3. The trigger input port	IN1~12	Initial value: no definition. Select the digital input port corresponding to the function signal. The input port “ 0 is not defined” means that the function is not defined.
4. The output signal port	OUT1~16	Initial value: no definition. Select the digital output port corresponding to the function signal. The output port “ 0 is not defined” means that the function is not defined.
5. Delay on time	Unit s	Initial value: 0.0 ; Range: 0.0~99.9 . After the trigger signal is valid, the logic output

		signal is valid after the delay.
6. Delayed disconnection time	Unit s	Initial value: 0.0 ; Range: 0.0~99.9 . After the trigger signal is invalid, the logic output signal will be invalid after the delay.
7. Output effective time	Unit s	Initial value: 0.0 ; Range: 0.0~99.9 . The duration after the logic output signal is valid, and becomes invalid after the end of the time.
8. Logic threshold weight	Unit KG	Initial value: 0.0 0 ; Range: 0.0~ 100.00 . Set the weight value, the current weight and the threshold weight comparison , and trigger when theweight value trigger condition is met .(When the trigger select "> =, or <=weight value" valid).

3. 8 .1 delay on

● When the delay is turned on [Custom Input Port Trigger], the operation is as follows:

1. Set parameters and switch quantity: type selection [delay turn-on], trigger signal If [Custom trigger input] is selected, the trigger input port is defined as " 1 " (you can see that the switch input port 1 is displayed as "auxiliary logic" Trigger input 1 "), the logic output port is defined as " 1 " (you can see that the digital output port 1 is displayed as "auxiliary logic output 1 "), and the [delay on time] is set to 2 seconds.

2. Execute operation: make the trigger signal input 1 valid, start the delay delay on time, and continue to be valid until the delay on time 2s ends, the logic output signal port 1 output is valid until the trigger signal input 1 is invalid, the logic output Signal port 1 also becomes invalid. See the timing diagram below:

● When the delay is turned on [fixed input port trigger], the operation is as follows:

1. Set parameters and switch quantity: trigger signal to select "input port 1 " (you can see that the digital input port 1 is displayed as "the original unchanged definition", assuming the original definition is start, the function of input port 1 can be "start" "It can also be "signal trigger"), the logic output port is defined as 1 (the switch output port 1 can be seen as "auxiliary logic output 1 "), and the [delay on time] is set to 2 seconds.

2. Execution operation: make the trigger signal input 1 valid (starting is also valid, the instrument running output is valid), start the delay-on time, and remain valid until the delay-on time is 2s , the logic output signal port 1 output is valid. Until the trigger signal input 1 is invalid, the logic output signal port 1 also becomes invalid. The meter will continue to run until an emergency stop signal is given.


● When the delay is turned on [switch output definition trigger], the operation is as follows:

1. Set parameters and switch quantity: trigger signal select "Run" (switch output can define or not define running signal), logic output port is defined as 1 (can see that switch output port 1 is displayed as auxiliary logic output 1), [Delayed On Time] is set for 2 seconds.


2. Execution operation: After the external input "start", when the "run" output signal is valid, it starts to go [delayed on time], and remains valid until the end of the delay on time 2s , the output of the logic output signal port 1 is valid. The logic output signal port 1 becomes invalid until the "Emergency stop or pause" is valid and the "Run" output signal is invalid.

● When the delay is turned on [> = or < = weight value trigger], the operation is as follows:

1. Set the corresponding threshold weight, the logic output port is defined as 1 (you can see that the switch output port 1 is displayed as the auxiliary logic output 1), and the [delayed on time] is set to 2 seconds.
2. Execution operation: current weight value \geq or \leq logic 1 threshold weight is valid when setting value , start to go [delay on time], it is valid until the end of delay on time 2s , logic output signal port 1 The output is valid until the current weight $<$ or $>$ logic 1 threshold weight setting value is invalid for logic output signal port 1 .




3. 8 .2 delay off
- Related parameters: Type selection [delay disconnect], select [trigger signal], set [trigger input port], [logic output port definition], [delay disconnect time]. Operation Reference "3.8 .1-Delay."Its output function is shown below:



3. 8 .3 delay on and delay off
- Related parameters: Type selection [delay on and delay off], select [trigger signal], set [trigger input port], [logic output port definition], [delay on time], [delayed off time】 . Operation Reference "3.8 .1-Delay." Its output function is shown below:


User Logic
Delay ON & Delay OFF Sequence chart



3. 8 .4 invalid - valid edge triggered

Related parameters: Type selection [invalid - valid edge trigger], select [trigger signal], set [trigger input port], [logic output port definition], [delay on time]. Operation Reference "3.8 .1-Delay." Its output function is shown below:


User Logic
OFF-ON,Edge Trigger Sequence chart



3. 8 .5 valid - invalid edge trigger

Related parameters: Type selection [valid - invalid edge trigger], select [trigger signal], set [trigger input port], [logic output port definition], [delay on time]. Operation Reference "3.8 .1-Delay." Its output function is shown below:

User Logic
ON-OFF,Edge Trigger Sequence chart



3.9 User Management

Administrators and system administrators can use the "User Management" item to perform user switching , user editing, and setting up automatic login users.

Under the user management interface

- ◆ Click the sub-option button to enter the current parameter item to view and set the attribution parameter information.
- ◆ Press [Back] to exit the current interface and return to the previous interface.
- ◆ After the meter is powered on, the default is to log in with “operator” privileges.
- ◆ Click the user to log in. The operator and administrator login initial password is **000000 (six zeros)**.
- ◆ Under [User Management], you can manage user passwords and implement hierarchical management of permissions.

In order to prevent the malfunction of the instrument caused by the malfunction of the instrument, the **GM9907** packaging controller provides **three** levels of authority (operator, administrator and system administrator) to choose: where the **system administrator can perform all operations on the meter** (not open to the user) . Operator and administrator permissions are as follows:

User level	Permission
operator	Quantitative values of the parameters can be set, can be calibrated, can be modified, the test switch, and is not limited in cumulative batch menu. Other parameters can be viewed, but not to modify.
administrator	You can not perform all the functions of "Reset / Backup" page.
Systemadministrator	All operations are not restricted .

User Management	Information child	Description
user list	user list	Show logged in users. 0 ~ 7 for the operator, 8 for the administrator, 9 is the system administrator (highest authority).
User editing	1. Login user	The currently logged in user is displayed. This item is not allowed to be modified.

	2. ID	Write the user ID to be edited .
	2. Permissions	Both administrator/operator options are available .
	3. Password switch	“On/Off” is optional. When set to off, the current login user does not need to enter a password when logging in.
	4. Password	Set/modify the login password. When setting the password, you need to enter the original password correctly. For the new password, you need to enter the same password twice, and fix 6 digits.
automatic log-in	automatic log-in	Set the automatic login user 0 ~ 8 or the last login user . (Note: When logging in as the system administrator last time, the default login is operator 0).

3.10 System Information

Administrators and system administrators can view meter version, password management, data recovery and backup, and shortcut key definitions through the System Information item.

Under the system information interface

- ◆ Click the sub-option button to enter the current parameter item to view and set the attribution parameter information.
- ◆ Press [Back] to exit the current interface and return to the previous interface.

System information item	Information child	Description
Version Information	Version Information	View the compilation date and time of the front and back , the corresponding version information , S/N code, P/N code and current date and time (you can modify the current date and time on this interface) .
Password management	1. Recipe parameter password	“On/Off” is optional. When set to off, the user does not need to enter a password to enter the corresponding parameters. Set to On to modify the password value of the selected parameter item. The user needs to enter the password to enter the corresponding parameter. Note: The national standard requires that the calibration scale parameters of the metered product must be protected by a password, so the calibration scale password
	2. System and communication password	
	3. Peripheral parameter password	
	4. Motor parameter password	
	5. School scale password	
	6. Accumulation clear	

	password	switch is fixed to “on” . Initial password: 000000
	7. Switch password	
	8 auxiliary logic password parameter	
	9. System information password	
Recovery/backup	1. Reset all parameters(including calibration scale)	Click this to restore all the parameter values of the instrument to the factory settings. (except system information)
	2. All parameters are reset (not including school scale)	Click the recovery in addition to the school scale parameter other parameters to the factory defaults. (except system information)
	3. Reset formulation parameters	Click this to restore the recipe parameter value to the factory setting.
	4. Communication system reset parameters	Click this to restore the system and communication parameter values to the factory settings.
	5. Peripheral Reset parameter	Click this to restore the peripheral parameter values to the factory settings.
	6. Reset motor parameters	Click this to restore the motor parameter value to the factory setting.
	7. Reset the school scale parameter	Click this to restore the calibration scale parameter value to the factory setting value.
	8 Reset switch parameters	Click this to restore the switch definition parameter value to the factory setting value.
	9. auxiliary reset logic parameters	Click this to restore the auxiliary logic parameter value to the factory setting value.
	10 Reset defined shortcuts	Click this to restore the shortcut key to the factory setting value.
	11. backup execution parameter	Click on the meter to back up the current parameter settings.
	12. Perform a recovery backup	Click the meter to restore the parameter value to the most recent backup value.
	13. Delete backup	Click the meter to delete the backed up parameters.
USB data export	1. All parameters	Export all parameters from USB .
	2. formulation parameters	Export recipe parameters from USB .
	3. System and communication parameters	Export system and communication parameters from USB .
	4. Peripheral parameters	Export peripheral parameters from USB .
	5. The motor parameters	Export motor parameters from USB .
	6. The school scale data	Export calibration scale parameters from USB .

	7. Cumulative data	Cumulative export parametersfrom US B .	
	8. binary parameters	Export the switch parametersfrom USB .	
	9. Auxiliary logicparameters	Export auxiliary logicparameters from USB .	
	10. Shortcut Keys	Export shortcut key parametersfrom USB .	
USB data export	1. All parameters	Import all parameters from USB .	
	2. formulation parameters	Import recipe parameters from USB .	
	3. System and communicationparameters	Import system and communicationparameters from USB .	
	4. Peripheral parameters	Import peripheral parametersfrom USB .	
	5. The motor parameters	Import motor parameters from USB .	
	6. The school scale data	Import calibration scaleparameters from USB .	
	7. binary parameters	Import cumulative parametersfrom USB .	
	8 auxiliary logicparameters	Import the switch parametersfrom USB .	
	9. shortcutsparameters	Import auxiliary logicparameters from USB .	
Shortcut definition	1. Shortcuts - 1	Initial value:quantitative value	Click to select the button function. Use the [Previous] key and the [Next] key to select the page to be searched (9 pages intotal) Note : For the defined shortcut keys, in the shortcut key view interface, click the corresponding button to enter the corresponding parameters, such as: theshortcut key 1initially defaults to “quantitative value ”, in the shortcut key view interface, press the shortcut key 1to enter "quantitativevalue" screen.If the shortcut key 1 is defined as "start", click Start to start the meter.
	2. Shortcuts - 2	Initial value: time parameter	
	3. Shortcuts - 3	Initial value:weighing parameter	
	4. Shortcuts - 4	Initial value: weight calibration scale	
	5. Shortcuts - 5	Initial value: motor parameters	
	6. Shortcuts - 6	Initial value: feeding parameters	
	7. Shortcuts - 7	Initial value: digital input test	
	8. Shortcuts - 8	Initial value: switch output test	
other settings	1. Language mode	Switch between Chinese and English. Initial value: Simplified Chinese; 0 : Simplified Chinese; 1 : English .	

	2. Screen brightness	Screen brightness selection.Initial value: 100% ; Optional: 0:10% ; 1:30% ; 2:50% ; 3:70% ; 4:80% ; 5: 100% .
	3. Screen saver time	Screen saver time setting.Initial value: 5 points; Optional: 0 : always on; 1 : 1 point; 2 : 2 points; 3 : 3 points; 4 : 5 points; 5 : 10 points.
	4. Screen saver selection	The screen is displayed when the screen saver is displayed. Initial value: display time; Optional: 0 : None; 1 : Display weight; 2 : Display time.

4. Function

4.1 Setting the working mode

The **GM9907- L2** has **five** scale body structures . Choose between the system and the communication - scale structure.

They are : hopper scale, hopper less scale, **PLC** mode , big mouth scales, valve scales .

(Note: Among them, the working mode of the bucket scale and the bucketless scale supports the dual scale interlock mode. Other scales do not support the dual scale interlock mode)

4.2 batches

The batch number is used for reminder of the number of packages. When the set number of batches is completed during the automatic running process, the meter issues the batch number to the alarm and stops, waiting for the user to process, the batch number and the alarm output are valid. At this time, press the clear alarm button or make The “clear alarm” input signal is valid and the meter will clear the above alarm. If the batch number is set to **0** , the batch number judgment is not performed.

The batch number ranges from **0 to 50000** . The initial default value is **0** (no batch count judgment).

4.3 level control

Due to the different application conditions, the filling device of the storage scale storage bin is divided into **two** types: double material level (upper and lower material level), single material level (lower material level) and no level positioner.

4 .3.1 double digit

The upper and lower material levels are defined, corresponding to the double material level. At this time, the instrument has a feeding control function, and the control principle is: when the upper and lower material level inputs are invalid, the instrument feeding output is valid; when the feeding level input is valid, the feeding output is invalid. At the same time, before each feeding (fast , medium, slow), the meter will check whether the lower level is valid. If it is invalid, wait for this signal; only when this signal is valid, the feeding process starts. During the feeding process, the meter does not detect whether the material level signal is valid.

Single Level 4 .3.2

The blanking level is defined, and the loading level is not defined, corresponding to the single material level. At this point the meter will not perform feed control. Only the feed level is detected before feeding. If the material level is invalid, wait for this signal; only when this signal is valid, the feeding process starts. During the feeding process, the meter does not detect whether the material level signal is valid.

The upper and lower material levels are not defined, corresponding to the situation without the positioner. At this time, the meter does not perform the feeding control, and the raw material level is not detected before the feeding.

4 .4 quick setup

In the stopped state, the quickly modified recipe data is saved in real time.

The data modified during operation, the zero zone value is saved in real time, and other recipe parameters are automatically updated when the next scale is started after exiting the quick setting interface (the combination mode is to be released after the loose bag is started and the next scale target value is updated).

The recipe parameters are modified during operation , but when the next scale is updated, the emergency stop signal is entered and the meter is stopped and the recipe is updated immediately.

M odbus can also be carried out at runtime when communicating recipe quantitative value changes, but can not modify the recipe number.

4.5 Adaptive function

The adaptive function is a convenient function to adjust the feeding speed when the user first uses the meter. When this function is turned on, it will automatically adjust the parameters such as the fast increase advance amount, the medium increase advance amount, the slow increase advance amount, the fast add ban time, the medium plus ban time, and the slow add time. The feeding process is optimized.

note:

- 1. All advances must be zero in order to be used normally.
- 2. If the drop correction and the adaptive function are turned on at the same time, the drop correction function is forcibly turned off.
- 3. When the first scale is adaptively started, the scale body must be stable and the current weight is zero.

4 . 6 U disk upgrade software

Proceed as follows:

1.	Insert the USB flash drive into the computer and create a new " GM9907-L2 " folder in the USB flash drive ;
2.	Save the " GM9907-L -Upload.gm " upgrade file to the " GM9907-L2 " folder;
3.	In the main instrument display screen and stopped the U disk plug in the instrument's USB port, it will automatically pop-up "system prompt" dialog box: " <input type="radio"/> Update [firmware] <input type="radio"/> Update [boot screen] confirm cancellation";
4.	Click the update [Firmware] as prompted , then <input type="radio"/> becomes <input checked="" type="radio"/> , click "OK" to start the firmware update process, wait for the progress bar to finish, the upgrade is successful, the instrument automatically restarts. It is

	<p>not allowed to power off or unplug the USB flash drive during the upgrade process . If the upgrade process is interrupted or the U disk is removed, after the power is turned back on, the software version before the upgrade will be retained, and the U disk update will be inserted again . After the progress bar is finished, the upgrade is successful and the instrument automatically restarts. .</p>
--	--

4 . 7 U disk upgrade boot interface

Proceed as follows:

1.	<p>Insert the USB flash drive into the computer and create a new “ GM9907-L2 ” folder in the USB flash drive ;</p>
2.	<p>Save the image of “ GM9907-L - Logo .bmp ” (resolution 1024*600) into the “ GM9907-L2 ” folder;</p>
3.	<p>In the main instrument display screen and stopped the U disk plug in the instrument’s USB port, it will automatically pop-up “system prompt” dialog box:</p> <div> <div> <input type="radio"/> Update [firmware] </div> <div> <input type="radio"/> Update [boot screen] </div> <div>confirm cancellation”;</div> </div>
4.	<p>According to remind click</p> <p>Update [boot interface], it becomes <input type="radio"/> <input checked="" type="radio"/>,pictures start the update process, after the upgrade, the instrument automatically restart after clicking “OK.” It is not allowed to power off or unplug the USB flash drive during the upgrade process . If the upgrade process is interrupted or the U disk is removed, after the power is turned back on, the picture</p>

	before the upgrade will be retained, and the U disk update will be inserted again . After the upgrade is successful, the instrument automatically restarts.
--	---

5. Serial communication

GM9907 provides two serial communication interface, and serial port **1** and **2** can be selected in a continuous manner, **Modbus** mode and printed three kinds of functions. The first serial port of the meter is **RS - 232** and the second serial port of the meter is **RS - 485** .

5.1 printing method

When the serial port serial port **1** or serial port **2** is selected as the **printing** mode, the corresponding serial port can realize the printing of the related accumulated content by connecting the serial printer.

The communication parameters related to the printing method refer to the serial port parameter items, among which are noted:

- 1) Baud Rate** - This parameter should be selected in accordance with the printer settings used for the connection.
- 2) Communication Format** - This parameter should be selected in accordance with the printer settings used for the connection.

Note: When the print language is selected as Chinese, the data bit cannot be used in 7-bit format, otherwise there will be an error in printing.

- 3) Print Format** - The peripheral **format** allows you to set the print format to **24** columns or **32** columns . In addition , the print language of the peripheral parameters is set to Chinese or English.

5.1.1 Automatic printing

In the **print** mode, the automatic print switch for peripheral parameters is set to **On** . Then, each time the weighing of the meter is completed, the weighing result will be printed automatically. The format is as follows:

<p>The Chinese 24 column print format is as follows:</p> <p>Packing schedule</p> <p>Unit : kg</p> <p>Recipe number : 20</p> <p>Total cumulative results</p> <p>-----</p> <p>1 5.50</p> <p>2 5.50</p>	<p>The Chinese 32 column print format is as follows:</p> <p>Packing schedule</p> <p>Unit: kg</p> <p>Recipe number: 20</p> <p>Total cumulative count target value result</p> <p>-----</p> <p>3 5.60 5.50</p> <p>4 6.00 5.80</p>
--	--

5 .1.2 total cumulative printing

<p>The Chinese 24 column print format is as follows:</p> <p>Total cumulative report</p> <p>Time: 2018/6/19 13:28</p> <p>Unit: kg</p> <p>-----</p> <p>Number of times: 18</p> <p>Weight: 84.16</p> <p>-----</p>	<p>The Chinese 32 column print format is as follows:</p> <p>Total cumulative report</p> <p>Time: 2018/6/19 13:36</p> <p>Unit: kg</p> <p>-----</p> <p>Number of times: 24</p> <p>Weight: 129.40</p> <p>-----</p>
--	---

In the **printing** mode, stop the state, enter the “Accumulate and Batch” interface, and click “Print Total Accumulation” . The format is as follows:

5 .1. 3 formula cumulative printing

In the printing mode, stop the state and enter the “Accumulate and Batch” interface. Select “Recipe Accumulation” and click “Print Selected Receipts” .

Click the “Print all the recipes rolled-up” to print all the recipes **(1 to 20)** accumulated, the instrument will automatically skip the cumulative recipe **0** does not print. The format is as follows:

<p>The Chinese 24 column print format is as follows:</p> <p>All formula accumulation report Time: 2018/6/19 13:29 Unit: kg</p> <p>-----</p> <p>Recipe number: 20 Number of times: 18 Weight: 84.16</p> <p>-----</p>	<p>The Chinese 32 column print format is as follows:</p> <p>All formula accumulation report Time: 2018/6/19 13:36 Unit: kg</p> <p>-----</p> <p>Recipe number: 20 Number of times: 24 Weight: 129.40</p> <p>-----</p>
--	---

5 .1.4 user cumulative printing

In the printing mode, stop the state and enter the “Accumulate and Batch” interface. Switch to the user cumulative interface and press “Print Selected User Accumulation”.

Click “Print All Users Accumulate” to print the total of all users (**0~9**). The meter will automatically skip users whose user accumulation is **0** and will not print. The format is as follows:

<p>The Chinese 24 column print format is as follows:</p> <p>Cumulative report for all users Time :2018/6/19 13:29</p> <p>Unit :kg</p> <p>-----</p> <p>User Number :9</p> <p>Number of times :16</p> <p>Weight :72.26</p> <p>-----</p>	<p>The Chinese 32 column print format is as follows:</p> <p>Cumulative report for all users Time: 2018/6/19 13:37 Unit: kg</p> <p>-----</p> <p>User Number: 9</p> <p>Number of times : 22</p> <p>Weight: 117.50</p> <p>-----</p>
--	---

5.2 continuous mode data frame format

STX	Scale number	R	T	SP	SP	Cumulative number	,	Cumulative weight	CRC	CR	LF
-----	--------------	---	---	----	----	-------------------	---	-------------------	-----	----	----

among them:

R -- 52H

T -- 54H

SP -- 20 H

Cumulative number - 9 digits, 000000000~999999999

Cumulative weight - 10 digits, including decimal point

For example, the meter sends the following data (in hexadecimal form):

02 30 31 52 54 20 20 20 20 20 20 20 20 20 31 30 30 2C 20 20 20 20 30 2E 35 30 30 30 32 39 0D 0A

It means: 1# scale, the current total cumulative number is 100 times, the total cumulative weight is 0.5000 .

5 .3 Modbus-RTU protocol

The communication mode selected on serial port 1 or serial port 2 is Modbus. -RTU mode .

Note : This address is not available if MD-R (compatible with 01. version) communication mode is selected .

5 3.1 abnormal function code and code

◆ Function code supported by the instrument:

function code	name	Description
03	Read register	Read up to 125 registers in a single pass .
06	Write a single register	Use this function code to write a single holding register.
10	Write multiple registers	This instrument only supports writing double registers. It must be aligned when writing. It is not allowed to write only a part of dual registers. Read-only part is allowed when reading.
01	Reading coil	Note that this length is in bits .

05	Write coil	
-----------	------------	--

Note: This instrument only supports the above MODBUS function code. When the instrument performs other function codes, the meter will not respond.

◆ MODBUS exception code response

Code	name	meaning
02	Illegal data address	For the instrument, the error code indicates that the data address received is an address that is not allowed.
03	Illegal data value	The portion of data written and the allowed range.
04	Slave failure	An unrecoverable error occurs when the meter is attempting to perform the requested operation.
07	Unsuccessful programming request	For the meter, the received command cannot be executed under the current conditions.

5. 3.2 MODBUS transmission mode

The **MODBUS** transmission mode is the **RTU** mode.

When communication with the **RTU** mode, information of each **8-bit** byte is divided into **two 4-bit** transmission character **hexadecimal**.

Data format: **8** -bit data bit, **1** stop bit, even parity (**8-E-1**)

8 -bit data bit, **1** stop bit, no parity (**8-N-1**)

Baud rate: **9600/19200/38400/57600/115200** (optional)

Code: **RTU**

Example :

Read command:

Command function	Slave number	function code	Data address	Number of data read	CRC check
------------------	--------------	---------------	--------------	---------------------	-----------

(single /double) byte					code	
Read weight (double)	01	03	0002	0002	65	CB
Target value (double)	01	03	01F6	0002	25	C5
Zero voltage (double)	01	03	0069	0002	14	17
Gain voltage (double)	01	03	006B	0002	B5	D7

Write command:

(Note: Write weight data with 50 as an example. When it is displayed as two decimal places, it should be written to 5000)

Command function (single /double) byte	Slave number	function code	Data address	Write register number	Write bytes	data input	CRCcheck code	
Write target value (double)	01	10	01F6	0002	04	0000 1388	7C	07
Zero calibration (double)	01	10	0069	0002	04	0000 0001	F4	2D
Gain calibration (double)	01	10	006B	0002	04	0000 1388	B9	62

5. 3.3 MODBUS address allocation

Protocol address	PLC address	meaning	Description		
000 0	4 0001	Gross weight	The meter displays the gross weight value, signed integer		
0001	4 000 2				
0002	4 000 3	net weight	The meter displays the net weight value, signed integer		
0003	4 000 4				
0004	4 000 5	Tare	Tare value		
0005	4 000 6				
000 6	4 000 7	Control status (bit)	Bit	Description	
			. 0	Unstable weight : 0 ; stable : 1	
			. 1	Non-zero : 0 ; zero : 1	
			. 2	Currently showing the weight of the symbol +/- Positive sign : 0 ; minus sign : 1	
. 3	overflow				
000 7	4 000 8		. 4	Weight overflow	
			. 5	Negative weight overflow	
			. 6	Sensor is overflowing	
			. 7	Sensor negative overflow	
			. 8	Millivolts stable: 1 unstable: 0	
			. 9~ . 31	Reserved	
000 8	4 000 9		Operating status	. 0	0 : stop; 1 : run
				. 1	Before feeding
		. 2		Quick add	
		. 3		China and Canada	
		. 4		Slow plus	
		. 5		Value	
		. 6		Weigh	
		. 7		Unloading	
		. 8		Zero zone	
		. 9		Very bad	
		. 10		Poor	
. 11	qualified				
000 9	4 0 0 10	. 12		Super short break	
		. 13		Clip pocket	
		. 14		Bag signal (valve)	
		. 15		Push bag signal (valve)	
		. 16		Hanging bag (ton pack)	

			. 17	Blowing (ton pack)
			. 18	Return air valve (ton pack)
			. 19	Metering bracket up(ton pack)
			. 20	Measuring bracket down (electric) (ton pack)
			. 21	Upper limit (PLCmode)
			. 22	Lower limit (PLCmode)
			. 23	Batch completion
			. 24	Call the police
			. 25	Gross weight status: 1 : Net weight, :0 : Gross weight
00 10	4 0 0 11	Control state 2	. 0	Double scale interlock output (interlock mode)
			. 1	Feed level
			. 2	Cutting level
			. 3	supply
			. 4	Missing material
			. 5	Cutting
			. 6	Shooting bag
			. 7	add mosaic
			. 8	Unloading rapping
			. 9	Conveyor output
			. 10	Sewing machine output
			. 11	Tangential machine output
00 11	4 0 0 12		. 12	Auxiliary pulse 1
			. 13	Auxiliary pulse 2
			. 14	Auxiliary pulse 3
			. 15	Auxiliary pulse 4
			. 16	Auxiliary logic output 1
			. 17	Auxiliary logic output 2
			. 18	Auxiliary logic output 3
			. 19	Auxiliary logic output 4
			. 20	Auxiliary logic output 5
			. 21	Auxiliary logic output 6
			. 22	Belt A (ton pack)(retained)
			. 23	Belt B (ton pack)(retained)
			. 24	Manual slow addition
			. 25	Manual unloading
00 12 ~0 013	4 0 0 13 ~ 4 00 14	Reserved		
00 14	4 0 0 15	Automatic clear	. 0	Target value is 0, unable to start

0015	40016	alarm	.1	Weight overflow atstartup
			.2	Clear over range
			.3	Clearing instability
			.4	Super low alarm
			.5	Disconnecting the discharge limit alarm
			.6	Reserved
			.7	Cleared during operation
			.8	Automatic clearing overrange
			.9	Automatic zeroing instability
			.10	Feeding door is not closed in place alarm
			.11	The discharge door is not closed in place.
			.12	Ordinary motor feeding, slow plus opening time setting cannot be0
			.13	Ordinary motor feeding, the opening time of the medium plus can not be less than the slow opening time
			.14	Ordinary motor feeding, fast opening time can not be less than the time of opening the door
			.15	Ordinary motor feeding, fast opening time can not be less than slow opening time
			.16	Running stability timeout
0016 ~0019	40017 ~ 40020	Reserved		
0020	40021	Manually clear the alarm	.0	Batch completion
			.1	Super short break
			.2	Motor feed door closes timeout
			.3	Pocket timeout
			.4	Loose bag timeout
			.5	Discharge closing timeout
			.6	Unloading timeout
			.7	Reserved
			.8	Reserved
0021	40022		.9	Motherboard add-on board communication failed
			.10	Fast feed timeout
			.11	Medium feed timeout
			.12	Slow feed timeout
			.13	Unloading timeout
			.14	Unloading rapping timeout
0022 ~0025	40023 ~ 40026		Reserved	

0026	4 0 0 27	Calibration alarm		
			1 : The maximum range is too small	
			2 : The maximum range is too large	
			3 : Zero voltage is too high	
			4 : Zero voltage is too low	
			5 : Zero voltage instability	
			6 : The gain voltage is too large	
			7 : The gain voltage is too small	
			8 : Gain voltage instability	
			9 : Weight input error	
			10 : The resolution is too small after calibration (not enough accuracy)	
0027	4 00 28			
0028	4 0 0 29	Alarm 3	Reserved	
0029	4 0 0 30			
0030	4 0 0 31	Total cumulative weight is 6digits	(real time parameters) Read only	
0031	4 0 0 32			
0032	4 0 0 33	The total cumulative weight low 9		
0033	4 0 0 34			
0034	4 0 0 35	Total accumulated number of packets		
0035	4 00 36			
0036	4 0 0 37	Current formula cumulative weight is 6 digits high		
0037	4 0 0 38			
0038	4 0 0 39	The current recipe cumulative weight low 9		
0039	4 0 0 40			
0040	4 00 41	Current formula cumulative number of packages		
0041	4 0 0 42			
0042	4 0 0 43	User cumulative weight is 6digits		
0043	4 0 0 44			
0044	4 0 0 45	User cumulative weight is 9digits lower		
0045	4 0 0 46			
004 6	4 00 47	User cumulative number of packets		
0047	4 00 48			
0048	4 0 0 49	Batch remaining		
0049	4 0 0 50	Fast time		
0050	4 0 0 51	China-Canada time		
0051	4 00 52	Slow time		

0052	4 0 0 53	Setting time		
0053	4 00 54	Discharge time		
0054	4 000 55	Previous package time		
0055	4 00 56	Previous bag weight		
0056	4 0 0 57			
0057	4 0 0 58	Packing speed		Package / hour
0058	4 0 0 59			
0059	4 0 0 60	Flow rate		(unit) / hour
0060	4 0 0 61			
0061 ~0099	4 0 0 62 ~ 40100	Reserved		
Readable and writable register				
Calibration parameters (reserved 100~200)				
0 100	4 0101	unit	Initial value : 1 ; 0 — g , 1 — kg , 2 — t , 3 :lb (lbs)	
0 101	4 0102	Decimal point	Initial value : 2 ; Optional: 0 — 0 digits; 1 — 1digit; 2 — 2 digits; 3 - 3 digits; 4 - 4 digits .	
0 102	4 0103	Graduation value	Initial value: 1 ; Optional: (1/ 2/ 5/ 10/ 20/ 50) .	
0103	4 0104	Maximum range	Initial value: 10000 ; Write range (maximum range value minimum scale ≤ × 10 0000, andnot more than 999,999)	
0 104	4 0105			
0 105	4 0106	Zero calibration	When writing 1 to the current weight as zero, the weighing is allowed to be written when the weighing platform is stable; the current zero millivolt is returned when reading.	
0106	4 0107			
0107	4 0108	Weight calibration gain	Enter the standard weight weight (≤ maximum range) ; Read as the current sensorrelative zero millivolts	
0108	4 0109			
0109	4 0110	Weightless Calibration (Millivolts) Gain	Write the millivolts corresponding to the gain weight, the meter is temporarily stored; when reading, it returns the absolute millivolts corresponding to the current weight (if the current millivolt is too small or too large, it cannot be calibrated and returns0XFFFF .).	
0110	4 00111			

0111	4 0112	No code gain calibration (weight)	Write and gain the weight value corresponding to millivolts. Before writing this value, you must first write the gain millivolts. When writing this register, use both to perform gain calibration. Returns 0000H when read .
0 112	4 0113		
0113	4 0114	Sensor sensitivity	3mV/V (Note 2) .
0114	4 0115	Instrument sensor voltage	The multimeter measures the voltage between EX + and EX - . (Note 2) .
0115	4 0116		
0 116	4 0117	Sensor maximum range	Initial value: 10000 ; (Note 2). Write range (maximum range value minimum scale \leq \times 10 0000 , andnot more than 999,999)
0 117	4 0118		
0 118~ 0199	4 0119~ 40200	Reserved	
System and communication parameters - weight parameters (reserved 200~500)			
0 200	4 0201	Stable range	Initial value : 2 ; Stable range (0 ~ 9 9 d optional)Unit: d
0 201	4 0202	Judgment time	Initial value: 0.3 ; range: 0.1~9.9 . (unit s)
0 202	4 0203	Clear range	Initial value: 50 ; Range : 1 -99 units: %
0 203	4 0204	Zero tracking range	Initial value: 0 ; Range : 0-9 Unit: d
0 204	4 0205	Zero tracking time	Initial value: 2.0 ; range: 0.1~99.9 . (unit s)
0 205	4 0206	A/D conversion rate	Initial value: 2 ; Optional: 0 : 120 times / sec; 1 : 24 0 times / sec; 2 : 480 times / sec; 3 : 9600 times / sec .
0206 ~ 0249	4 0207~ 40250	Reserved	
System and communication parameters - filter parameters			
0 250	4 0251	Stop filter level	Initial value: 7 ; Range: 0 to 9
0 251	4 0252	Secondary filter switch	Initial value: 0 ; 1 : On 0 : Off
0 252	4 0253	Dynamic filter switch	Initial value: 0 ; 1 : On ; 0 : Off
0 253	4 0254	Feed filter level	Initial value: 2 ; Range: 0 to 9
0254	4 0255	Fixed filter level	Initial value: 7 ; Range: 0 to 9
0 255	4 0256	Unloading filter level	Initial value: 1 ; Range: 0 to 9
0 256~ 0299	4 0257 ~ 40300	Reserved	
System and communication parameters - function parameters			
0 300	4 0301	Power-on automatic	Initial value: 0 ; 1 : On ; 0 : Off

		clear	
0 301	40302	Automatic clear interval	Initial value: 0 ; Range : 0-99 has the bucket to complete the packing and then clear the current weight.
0 302	40303	Running stability timeout	The initial value is 0 ; the range is 0 to 99.9 . (unit s)
0 303	40304	Setting method	Initial value: 0 ; (range: 0 , 1) 0 : judgment stable value ; 1 : delay setting
0 304	40305	Manual unloading	Initial value: 0 ; 1 : On ; 0 : Off
0 305	40306	Fixed weight retention	Initial value: 0 ; 1 : On ; 0 : Off
0 306	40307	Adaptive level	Initial value: 3 ; Range: 1 ~ 5
0 307	40308	Adaptive switch	Initial value: 0 ; Range: 0 ~ 2
0308 ~ 0349	40309 ~ 4 0350	Reserved	
System and communication parameters - structural parameters			
0 350	40351	Scale body structure	Initial value: 0 ; 0 : There are bucket scales; 1 : No bucket scale; 2 : PLC mode; 3 : ton pack scale; 4 : Valve scale.
0 351	40352	Operating mode	Initial value : 0 ; 0: single scale; 1: Interlock A; 2: interlock B.
0 352	40353	Packaging mode	Initial value: 1 ; 0: Gross weight packaging; 1: Net weight package.
0 353	40354	Bracket movement	Initial value: 0 ; 0 : pneumatic; 1 : electric.
0 354	40355	Feeding method	Initial value: 1 ; 0 : separate feeding ; 1 : combined feeding .
0 355	40356	Double scale loose bag mode	Initial value: 0 ; 0 : no loose bag at the same time ; 1 : At the same time loose bag 1; 2 : At the same time loose bag 2 .
0 356 ~ 0499	40357 ~ 40500	Reserved	
Recipe parameters - quantitative value parameters (reserved 500 ~ 1000)			
0 500	40501	Recipe number	Initial value 1 ; range: 1 to 20
0 501	40502		
0 502	40503	Target value	Weight value writing range : ≤ maximum range
0 503	40504		
0 504	40505	Faster advance	
0 505	40506		
0 506	40507	Medium and early advance	
0 507	40508		
0 508	40509	Drop difference	

0 509	40510		
0 510	40511	Zero zone value	
0 511	40512		
0 512~ 0549	40513 ~ 40550	Reserved	
Recipe parameter - time parameter			
0 550	40551	Delay before feeding	Initial value: 0. 5 ; range: 0 to99.9 . (unit s)
0 551	40552	Quickly add time	. Initial value: 09 ; range: 0 to99.9 . (unit s)
0 552	40553	Sino-Canada banned time	Initial value: 0. 9 ; range: 0 to99.9 . (unit s)
0 553	40554	Slowly add time	Initial value: 0. 9 ; range: 0 to99.9 . (unit s)
0 554	40555	Fixed value retention time	Initial value: 0. 5 ; range: 0 to99.9 . (unit s)
0 555	40556	Delay after pocket	Initial value: 0. 5 ; range: 0 to99.9 . (unit s)
0 556	4 0557	Time before loose bag	Initial value: 0. 5 ; range: 0 to99.9 . (unit s)
0 557	40558	Unloading delay	Initial value: 0. 5 ; range: 0 to99.9 . (unit s)
0 558~ 0599	40559~40600	Reserved	
Recipe parameters - super low error detection parameters			
0 600	40601	Super low detection switch	Initial value: 0 ; 1 : On ; 0 : Off
0 601	40602	Super low pause switch	Initial value: 0 ; 1 : On ; 0 : Off
0 602	40603	Super low alarm time	. Initial value: 10 ; range: 0 ~999 . (unit s)
0 603	40604	Tolerance value	Weight value writing range : ≤ maximum range
0 604	40605		
0 605	40606	Due to the difference	
0 606	40607		
0 607	40608	Underfeed switch	Initial value: 0 ; 1 : On ; 0 : Off.
0 608	40609	Undershoot maximum replenishment times	First: 1 ; range: 1 ~ 99 .
0 609	40610	Feeding effective time	Initial value: 0.5 ; range: 0 to 99 .9 . (unit s)
0 610	406011	Invalid feeding time	Initial value: 0.5 ; range: 0 to 99 .9 . (unit s)
Recipe parameters - drop correction parameters			
0 611	406012	Drop correction switch	Initial value: 0 ; 1 : On ; 0 : Off .
0 612	406013	Drop correction	Initial value: 1 ; Range: 1~99 .
0 613	406014	Drop correction range	Range: 2.0 ; Range: 0 to 9.9 (unit:%)

0 614	406015	Drop correction	Initial value: 1 ; Optional: 0--100 % correction; 1--50% correction; 2 - 25% correction.
Recipe parameters - slow plus jog			
0 615	406016	Slow plus jog switch	Initial value: 0 ; 1 : On ; 0 : Off .
0 616	406017	Jog effective time	Initial value : 0.5 ; range: 0 to9.9 . (unit s)
0 617	406018	Jog invalid time	Initial value : 0.5 ; range: 0 to9.9 . (unit s)
Recipe parameters - there are bucket parameters			
0 618	406019	Single combination number	First: 1 ; range: 0 ~ 99 .
0 619~ 0649	40620 ~ 40650	Reserved	
Recipe parameters - no bucket parameters			
0 650	406051	Bagging delay start time again	Initial value : 4.0 ; range: 0 to 99 .9 . (unit s)
0 651~ 0699	406052~40700	Reserved	
Recipe parameters - PLC mode			
0 700	40701	Super difference	0 ~ maximum range
0 701	40702		
0 702	40703	Underbalance	0 ~ maximum range
0 703	40704		
0 704	40705	Upper limit	0 ~ maximum range
0 705	40706		
0 706	40707	lower limit	0 ~ maximum range
0 707	40708		
0 708~ 0749	40709~40750	Reserved	
Recipe parameters - tons of scale mode			
0 750	40751	Hanger delay time	Initial value : 0.5 ; range: 0 to 99.9 . (unit s)
0 751	40752	Bracket automatic rise switch	Initial value: 0 ; 1 : On ; 0 : Off
0 752	40753	Bracket uplink delay time	Initial value: 5.0 ; range: 0 ~ 99.9 . (unit s)
0 753	40754	Bracket down delay time	Initial value: 5.0 ; range: 0 ~ 99.9 . (unit s)
0 754	40755	Metering bracket uplink timeout	Initial value: 5.0 ; range: 0 ~ 99.9 . (unit s)
0 755	40756	Metering bracket downlink timeout	Initial value: 5.0 ; range: 0 ~ 99.9 . (unit s)
0 756	40757	Blowing time	Initial value : 0.5 ; range: 0 to 99.9 . (unit s)
0 757	40758	Belt A running time (reserved)	Initial value: 5.0 ; range: 0 ~ 99.9 . (unit s)

0 758	40759	Belt B running time (reserved)	Initial value: 5.0 ; range: 0 ~ 99.9 . (unit s)
0 759~ 0799	40760~40800	Reserved	
Recipe parameters - valve port mode			
0 800	40801	Bag delay time	Initial value : 0.5 ; range: 0 to 99.9 . (unit s)
0 801	40802	Bag effective time	Initial value : 0.5 ; range: 0 to 99.9 . (unit s)
0 802	40803	Push bag delay time	Initial value : 0.5 ; range: 0 to 99.9 . (unit s)
0 803	40804	Push bag effective time	Initial value : 0.5 ; range: 0 to 99.9 . (unit s)
0 804~ 0999	40 804~ 41000	Reserved	
Peripheral parameters - beat (dock) bag parameters (reserved 1000~1200)			
1000	41001	Bag mode	Initial value: 0 ; Optional: 0 : Do not shoot the bag ; 1 : After the fixed value, the bag is taken ; 2 : Shooting bag in the feeding ; 3 : After the addition averagevalue and shot bags. There are buckets to set: 0,1 ; No bucket can be set: 0~3 .
1001	41002	Bag start weight	Initial value: 0 ; Range: 0 ~Maximum range.
1002	41003		
1003	41004	Number of shots in the feed	Initial value: 0 ; range: 0~99 . Set the parameters for the number of shots in the feed .
1004	41005	Number of shots after setting	Initial value: 4 ; Range: 0~99 . Set the parameters for the number of shots after the value is set .
1005	41006	Delay before the bag	Initial value: 0.5 ; range : 0~99.9 . (unit s) After the bag is started , the bag output is valid after this delay time.
1006	41007	Bag time	Initial value: 0.5 ; range: 0~99.9 . (unit s) During the on-off cycle of the bag, the bag output valid time.
1007	41008	Bag time invalid	Initial value: 0.5 ; range : 0~99.9 . (unit s) In the on-off cycle of the bag, the bag output invalid time.
1008	41009	Extra shot bag output effective time	Initial value: 0 ; range : 0~99.9 .(unit s)
1009~1019	41010 ~ 41020	Reserved	
Peripheral parameters - coding parameters			
1020	41021	Code switch	Initial value: 0 ; 1 : On ; 0 : Off .
1021	41022	Code start delay	Initial value: 0. 5 ; range: 0 to 99 .9 . (unit s)
1022	41023	Code valid time	Initial value: 0. 5 ; range: 0 to 99 .9 . (unit s)
1023	41024	Not be allowed to add a code whenunloading	Initial value: 0 ; 0 : The discharge output or the feed output is allowed to start during the coding process;

			1 : The discharge output or feed output is not allowed to start during the coding process.
1024~1029	41025~41030	Reserved	
Peripheral parameters - sewing machine parameters			
1030	41031	Sewing machine start delay	Initial value: 0.5 ; range: 0 to 99.9 . (unit s)
1031	41032	Sewing machine output effective time	Initial value: 4.0 ; range: 0 to 99.9 . (unit s)
1032	41033	Tangent output time	Initial value: 0.5 ; range: 0 to 99.9 . (unit s)
1033	41034	Delay before sewing machine	Initial value: 0.5 ; range: 0 to 99.9 . (unit s)
1034~1039	41035~41040	Reserved	
Peripheral parameters - unloading rapping parameters			
1040	41041	Unloading rapping switch	Initial value: 0 ; 1 : On ; 0 : Off .
1041	41042	Unloading effective time	Initial value: 2.0 ; range: 0 to 9.9 . (unit s)
1042	41043	Unloading rapping effective time	Initial value: 0.5 ; range: 0 to 9.9 . (unit s)
1043	41044	Unloading rapping invalid time	Initial value: 0.5 ; range: 0 to 9.9 . (unit s)
1044	41045	Unloading frequency	Initial value: 10 ; Range: 0 to 99 .
1045~1049	41046~41050	Reserved	
Peripheral parameters - loading and unloading timeout judgment parameters			
1050	41051	Loading and unloading timeout judgment switch	Initial value: 0 ; 1 : On ; 0 : Off .
1051	41052	Fast timeout	Initial value: 5.0 ; range: 0 to 99.9 . (unit s)
1052	41053	Medium plus timeout	Initial value: 5.0 ; range: 0 to 99.9 . (unit s)
1053	41054	Slow plus timeout	Initial value: 5.0 ; range: 0 to 99.9 . (unit s)
1054	41055	Discharge timeout	Initial value: 5.0 ; range: 0 to 99.9 . (unit s)
1055~1059	41056~41060	Reserved	
Peripheral parameters - auxiliary pulse parameters			
1060	41061	Auxiliary pulse 1execution total time	Initial value: 0.0 ; Range: 0 to 999.9 . (unit s)
1061	41062	Auxiliary pulse 1effective time	Initial value: 10.0 ; Range: 0 to 999.9 . (unit s)

1062	41063	Auxiliary pulse 1invalid time	Initial value: 10.0 ; Range: 0 to 9 9 9.9 . (unit s)
1063	41064	Auxiliary pulse 2execution total time	Initial value: 0.0 ; Range: 0 to 9 9 9.9 . (unit s)
1064	41065	Auxiliary pulse 2effective time	Initial value: 10.0 ; Range: 0 to 9 9 9.9 . (unit s)
1065	41066	Auxiliary pulse 2invalid time	Initial value: 10.0 ; Range: 0 to 9 9 9.9 . (unit s)
1066	41067	Auxiliary pulse 3execution total time	Initial value: 0.0 ; Range: 0 to 9 9 9.9 . (unit min)
1067	41068	Auxiliary pulse 3effective time	Initial value: 10.0 ; Range: 0 to 9 9 9.9 . (unit min)
1068	41069	Auxiliary pulse 3invalid time	Initial value: 10.0 ; Range: 0 to 9 9 9.9 . (unit min)
1069	41070	Auxiliary pulse 4execution total time	Initial value: 0.0 ; Range: 0 to 9 9 9.9 . (unit min)
1070	41071	Auxiliary pulse 4effective time	Initial value: 10.0 ; Range: 0 to 9 9 9.9 . (unit min)
1071	41072	Auxiliary pulse 4 invalid time	Initial value: 10.0 ; Range: 0 to 9 9 9.9 . (unit min)
1072~1079	41073~41080	Reserved	
Peripheral parameters - conveyor			
1080	41081	Conveyor switch	Initial value: 0 ; 1 : On ; 0 : Off .
1081	41082	Conveyor start delay	Initial value: 0.5 ; range: 0 to 99 .9 . (unit s)
1082	41083	Conveyor running time	Initial value: 4.0 ; range: 0 to 99 .9 . (unit s)
108 3 ~ 1089	4108 4 ~ 41090	Reserved	
Peripheral parameters - print parameters			
1090	1091	Automatic print switch	Initial value: 0 , 1 : On ; 0 : Off
1091	1092	Print format	Initial value : 0 ; 0 : 24 columns of printing ; 1 :32 columns of printing .
1092	1093	Print language	Initial value : 0 ; 0 : Chinese; 1: E nglish .
1093	1094	Print the number of lines	Initial value: 3 ; Range: 0 to 9 .
1094~1199	4 1095 ~41200	Reserved	

Auxiliary logic programming 1 -6 (reserved 1200~1400)			
1200	41 201	Types of	Initial value : 0 ; range 0~5 .
			0 : off
			1 : Delay on
			2 : Delayed disconnection
			3 : Delay on and delay off
			4 : Invalid - valid edge trigger
			5 : valid - invalid edge trigger
1201	41 202	Trigger signal	Initial value : 0 ; range: 0~64 . Can be selected from the definition of the trigger input port , fixed digital input port1~12 , digital output definition, weight value trigger.
1202	41 203	Trigger input signal port	Initial value : 0 ; range 0~12 . Select the digital input port 0~12corresponding to this function signal , and input port 0 means that this function is not defined.
1203	41 204	Output signal port	Initial value : 0 ; range 0~16 . Select the digital output port0~16 corresponding to the function signal , and the output port-0 means that the function is not defined.
1204	41 205	Delay on time	Initial value : 0 ; range: 0~99.9 .(unit s) After the trigger signal is valid, the logic output signal is valid after the delay.
1205	41 206	Delayed off time	Initial value : 0 ; range: 0~99.9 .(unit s) After the trigger signal is invalid, the logic output signal will be invalid after the delay.
1206	41 207	Signal output effective time	Initial value : 0 ; range: 0~99.9 .(unit s) The duration after the logic output signal is valid, and becomes invalid after the end of the time.
1207	41 208	Threshold weight	Initial value: 0 ; Range:0~999999
1208	41 209		When the trigger signal selects "Threshold Weight", the current weight is compared to this value.
1209 ~ 1219	41 210 ~41220	Reserved	
Auxiliary logic programming 2			
1220	41 221	Types of	Initial value : 0 ; range 0~5 .
			0 : off
			1 : Delay on
			2 : Delayed disconnection
			3 : Delay on and delay off
			4 : Invalid - valid edge trigger
			5 : valid - invalid edge trigger
1221	41 222	Trigger signal	Initial value : 0 ; range: 0~64 . Can be selected from the definition of the trigger input port , fixed

			digital input port 1~12 , digital output definition, weight value trigger.
1222	41 223	Trigger input signal port	Initial value : 0 ; range 0~12 . Select the digital input port 0~12 corresponding to this function signal , and input port 0 means that this function is not defined.
1223	41 224	Output signal port	Initial value : 0 ; range 0~16 . Select the digital output port 0~16 corresponding to the function signal , and the output port- 0 means that the function is not defined.
1224	41 225	Delay on time	Initial value : 0 ; range: 0~99.9 .(unit s) After the trigger signal is valid, the logic output signal is valid after the delay.
1225	41 226	Delayed off time	Initial value : 0 ; range: 0~99.9 .(unit s) After the trigger signal is invalid, the logic output signal will be invalid after the delay.
1226	41 227	Signal output effective time	Initial value : 0 ; range: 0~99.9 .(unit s) The duration after the logic output signal is valid, and becomes invalid after the end of the time.
1227	41228	Threshold weight	Initial value: 0 ; Range: 0~999999
1228	41229		When the trigger signal selects "Threshold Weight", the current weight is compared to this value.
1229 ~1239	41 230 ~ 41240	Reserved	
Auxiliary logic programming 3			
1240	41 241	Types of	Initial value : 0 ; range 0~5 .
			0 : off
			1 : Delay on
			2 : Delayed disconnection
			3 : Delay on and delay off
			4 : Invalid - valid edge trigger
			5 : valid - invalid edge trigger
1241	41 242	Trigger signal	Initial value : 0 ; range: 0~64 . Can be selected from the definition of the trigger input port , fixed digital input port 1~12 , digital output definition, weight value trigger.
1242	41 243	Trigger input signal port	Initial value : 0 ; range 0~12 . Select the digital input port 0~12 corresponding to this function signal , and input port 0 means that this function is not defined.
1243	41 244	Output signal port	Initial value : 0 ; range 0~16 . Select the digital output port 0~16 corresponding to the function signal , and the output port- 0 means that the function is not defined.
1244	41 245	Delay on time	Initial value : 0 ; range: 0~99.9 .(unit s)

			After the trigger signal is valid, the logic output signal is valid after the delay.
1245	41 246	Delayed off time	Initial value : 0 ; range: 0~99.9 .(unit s) After the trigger signal is invalid, the logic output signal will be invalid after the delay.
1246	41 247	Signal output effective time	Initial value : 0 ; range: 0~99.9 .(unit s) The duration after the logic output signal is valid, and becomes invalid after the end of the time.
1247	41248	Threshold weight	Initial value: 0 ; range: 0~999999 .
1248	41249		When the trigger signal selects "Threshold Weight", the current weight is compared to this value.
1249 ~ 1259	41 250 ~41260	Reserved	
Auxiliary logic programming 4			
1260	41 261	Types of	Initial value : 0 ; range 0~5 .
			0 : off
			1 : Delay on
			2 : Delayed disconnection
			3 : Delay on and delay off
			4 : Invalid - valid edge trigger
			5 : valid - invalid edge trigger
1261	41 262	Trigger signal	Initial value : 0 ; range: 0~64 . Can be selected from the definition of the trigger input port , fixed digital input port 1~12 , digital output definition, weight value trigger.
1262	41 263	Trigger input signal port	Initial value : 0 ; range 0~12 . Select the digital input port 0~12 corresponding to this function signal , and input port 0 means that this function is not defined.
1263	41 264	Output signal port	Initial value : 0 ; range 0~16 . Select the digital output port 0~16 corresponding to the function signal , and the output port- 0 means that the function is not defined.
1264	41 265	Delay on time	Initial value : 0 ; range: 0~99.9 .(unit s) After the trigger signal is valid, the logic output signal is valid after the delay.
1265	41 266	Delayed off time	Initial value : 0 ; range: 0~99.9 .(unit s) After the trigger signal is invalid, the logic output signal will be invalid after the delay.
1266	41 267	Signal output effective time	Initial value : 0 ; range: 0~99.9 .(unit s) The duration after the logic output signal is valid, and becomes invalid after the end of the time.
1267	41268	Threshold weight	Initial value: 0 , range: 0~999999 .
1268	41269		When the trigger signal selects "Threshold Weight", the current

			weight is compared to this value.
1269 ~ 1279	41 270 ~ 41280	Reserved	
Auxiliary logic programming 5			
1280	41281	Types of	Initial value : 0 ; range 0~5 .
			0 : off
			1 : Delay on
			2 : Delayed disconnection
			3 : Delay on and delay off
			4 : Invalid - valid edge trigger
			5 : valid - invalid edge trigger
1281	41282	Trigger signal	Initial value : 0 ; range: 0~64 . Can be selected from the definition of the trigger input port , fixed digital input port1~12 , digital output definition, weight value trigger.
1282	41283	Trigger input signal port	Initial value : 0 ; range 0~12 . Select the digital input port 0~12corresponding to this function signal , and input port 0 means that this function is not defined.
1283	41284	Output signal port	Initial value : 0 ; range 0~16 . Select the digital output port0~16 corresponding to the function signal , and the output port-0 means that the function is not defined.
1284	41285	Delay on time	Initial value : 0 ; range: 0~99.9 .(unit s) After the trigger signal is valid, the logic output signal is valid after the delay.
1285	41286	Delayed off time	Initial value : 0 ; range: 0~99.9 .(unit s) After the trigger signal is invalid, the logic output signal will be invalid after the delay.
1286	41287	Signal output effective time	Initial value : 0 ; range: 0~99.9 .(unit s) The duration after the logic output signal is valid, and becomes invalid after the end of the time.
1287	41288	Threshold weight	Initial value: 0 ; Range: 0~Maximum range.
1288	41289		When the trigger signal selects "Threshold Weight", the current weight is compared to this value.
1289 ~1299	41290~41300	Reserved	
Auxiliary logic programming 6			
1300	41301	Types of	Initial value : 0 ; range 0~5 .
			0 : off
			1 : Delay on
			2 : Delayed disconnection
			3 : Delay on and delay off
			4 : Invalid - valid edge trigger
			5 : valid - invalid edge trigger

1301	41302	Trigger signal	Initial value : 0 ; range: 0~64 . Can be selected from the definition of the trigger input port , fixed digital input port 1~12 , digital output definition, weight value trigger.
1302	41303	Trigger input signal port	Initial value : 0 ; range 0~12 . Select the digital input port 0~12 corresponding to this function signal , and input port 0 means that this function is not defined.
1303	41304	Output signal port	Initial value : 0 ; range 0~16 . Select the digital output port 0~16 corresponding to the function signal, and the output port- 0 means that the function is not defined.
1304	41305	Delay on time	Initial value : 0 ; range: 0~99.9 .(unit s) After the trigger signal is valid, the logic output signal is valid after the delay.
1305	41306	Delayed off time	Initial value : 0 ; range: 0~99.9 .(unit s) After the trigger signal is invalid, the logic output signal will be invalid after the delay.
1306	41307	Signal output effective time	Initial value : 0 ; range: 0~99.9 .(unit s) The duration after the logic output signal is valid, and becomes invalid after the end of the time.
1307	41308	Threshold weight	Initial value: 0 ; range: 0~999999 .
1308	41309		When the trigger signal selects "Threshold Weight", the current weight is compared to this value.
1309 ~ 1399	41310~41400	Reserved	
Motor parameters - feeding mode (reserved 1400~1600)			
1400	41400	Motor group number used in the current recipe	Initial value: 0 ; Range: 0~4
1401	41402	Feed mode	Initial value : 0 ; Optional: 0 : pneumatic feeding ; 1 :stepping motor feeding; 2 : Ordinary motor feeding .
1402	41403	Feeding gate closing timeout	Initial value: 4.0 ; range: 0~99.9 . (unit s)
1403	41404	Feed gate in-position signal type	Initial value: 0 ; Optional: 0 : The signal is in place when it is valid; 1 : When the signal is invalid, it is in place .
1404	41405	Motor group number	Initial value: 0 , range: 0~4
1405	41406	Feed motor frequency	Initial value : 12000 , range: 1~50000 Hz

1406	41407	Adding material to slow down and adding the required number of pulses	Initial value : 1800 ; range: 1~60000 .
1408	41409	The number of pulses required for feeding to close	Initial value : 4300 ; range: 1~60000 .
1410	41411	Feeding off to fast increase the number of pulses required	Initial value : 7750 ; range: 1~60000 .
1412	41413	Feed switch direction signal status	Initial value : 0 ; Optional: 0 : the door opening directionwhen the signal is valid ; 1 : The door opening directionis when the signal is invalid .
1413	41414	Feed motor starting frequency	Initial value : 2000 ; Range: 0~50000Hz (This value should preferably not be greater than the feeding motor frequency)
1414	41415	Feed motor acceleration time	Feed motor acceleration time Initial value: 200 ; Range: 0~9999 . (unit s)
1415	41416	Feed motor deceleration time	Feed motor deceleration time Initial value: 50 ; Range: 0~9999 . (in ms)
1416	41417	Quickly open the door	Initial value: 0.80 ; Range : 0~99.99 . (unit s)
1417	41418	China and Canadaopening time	Initial value: 0.40 ; Range: 0~99.99 . (unit s)
1418	41419	Slow opening time	Initial value: 0.20 ; Range: 0~99.99 . (unit s)

1419	41420	Bag mode	Initial value: 0 ; Optional: 0 : pneumatic clamp loose bag; 1 : stepper motor clip loose bag ; 2 : motor double limit clip loose bag; 3 : Motor single limit clip loose bag .
1420	41421	Loose bagprocesstimeout	Initial value: 3.0 ; Range: 0 ~ 99.9 . (unit s)
1421	41422	Baggingprocesstimeout	Initial value: 3.0 ; range: 0~99.9 . (unit s)
1422	41423	Loose bag in place signal type	Initial value: 0 ;

			Optional: 0 : The signal is in place when it is valid ; 1 : When the signal is invalid, it is in place .
1423	41424	Bag motor frequency	Initial value: 30000 ; Range: 1~50000 Hz .
1424	41425	Matsumoto motor frequency	Initial value: 20000 ; range: 1~50000 Hz .
1425	41426	The number of pulses required for the bag	Initial value: 12000 ; range: 1~60000 .
1426	41427		
1427	41428	Bag direction signal status	Initial value: 0 ; Optional: 0 : when the signal is invalid, it is the direction of the pocket; 1 : When the signal is valid, it is the direction of the pocket.
1428	41429	Bag motor starting frequency	Initial value: 2000 ; range: 0 ~ 50000 Hz . (This value cannot be greater than the pocket frequency)
1429	41430	Bag motor acceleration time	Initial value: 200 ; Range: 0~9999 . (in ms)
1430	41431	Bag motor deceleration time	Initial value: 50 ; Range: 0~9999 (in ms) .
1431	41432	Loose bag effective time	Initial value: 0.5 , range: 0~99.99 . (unit s)
1432	41433	Discharge mode	Initial value: pneumatic mode; 0 , pneumatic mode; 1 . Stepper motor unloading; 2 , motor single limit discharge; 3 , the motor double limit discharge; 4 . The motor rotates and unloads in one direction.
1433	41434	Discharge closing timeout	Initial value : 3.0 ; range: 0 ~ 99.9 . (unit s)
1434	41435	Unloading timeout	Initial value : 3.0 ; range: 0 ~ 99.9 . (unit s)
1435	41436	Discharge in place signal type	Initial value: 0 ; Optional: 0 , the signal is in place when it is valid . 1 . When the signal is invalid, it is in place .
1436	41437	Unloading limit real-time detection switch	Initial value : 0 ; 0 : off ; 1 : on.
1437	41438	Unloading door motor frequency	Initial value : 30000 ; range: 1~50000 (Hz) .
1438	41439	Discharge closing motor frequency	Initial value : 20000 ; range: 1~50000 (Hz) .
1439	41410	Number of pulses required for unloading	Initial value : 12000 ; range: 1~60000 .
1440	41411		

144 1	41412	Discharge direction signal status	Initial value : 0 ; Optional: 0 : the door opening direction when the signal is invalid 1: valid signal to the door opening direction
1442	41416	Unloading motor starting frequency	Initial value: 2000 ; range: 1~50000 (Hz) . (This value cannot be greater than the discharge frequency)
1443	41414	Unloading motor acceleration time	Initial value: 200 ; Range: 0~9999 . (in ms)
1444	41415	Unloading motor deceleration time	Initial value: 50 ; Range: 0~9999 . (in ms)
1445	41416	Unloading door opening time	Initial value: 1.00 ; Range: 0~99.99 . (unit s)
1446~1599	41417~41600	Reserved	
Communication parameters - serial port 1 parameters (reserved 1600~1700) 485			
1600	41601	Slave number	Initial value: 1 ; 1 ~ 9 9 optional.
1601	41602	communication method	0 : Modbus-RTU ; 1 : Print 2 : continuous mode 3 : MD-R (compatible with 01. version)
1602	41603	Baud rate	0 : 9600 1 : 119200 2 : 38400 3 : 57600 4 : 115200
1603	41604	Data Format	Communication data format selection (data bit, parity bit, stop bit . E : even parity; N : no parity) 0 : 8-E-1 1 : 8-N-1 2 : 7-E-1 3 : 7-N-1
1604	41605	High and low words	Initial value : 0 : The high word is in the front low word after ; Range : 0-1 0 : the high word is in the front low word after ; 1 : The low word is in the front high word .
Communication parameters - serial port 2 parameters 232			
1605	41606	Slave number	Initial value: 1 ; 1 ~ 9 9 optional.
1606	41607	communication method	0 : Modbus-RTU ; 1 : Print 2 : continuous mode 3 : MD-R (compatible with 01. version)

1607	41608	Baud rate	0 : 9600 1 : 119200 2 : 38400 3 : 57600 4 : 115200
1 608	41609	Data Format	Communication data format selection (data bit, parity bit, stop bit . E : even parity; N : no parity) 0 : 8-E-1 1 : 8-N-1 2 : 7-E-1 3 : 7-N-1
1609	41610	High and low words	Initial value : 0 : high word in front of low word after Range : 0-1 . 0 : the high word is in the front low word after ; 1 : The low word is in the front high word .
Communication parameters - network port parameters			
1610	41611	High and low byte	Initial value : 0 : The high word is in the front low word after ; Range : 0-1 . 0 : the high word is in the front low word after ; 1 : The low word is in the front high word .
1611	41612	The port number	Initial value: 502 ; Range: 1 ~ 65535
1 612	41613	IP	Initial value: 192.168.1 01 . 246 . Range: 0 ~ 255 .
1613	41614		
1614	41615		
1615	41616		
1616~1699	41617~41700	Reserved	
Switching custom parameters (reserved 1800~1900)			
1700	41701	Digital input port 1definition	write: Write the function corresponding value . If IN is defined as running, write 1 in the corresponding register of IN . read: Returns the current switch custom state
1701	41702	Digital input port 2definition	
1702	41703	Digital input port 3definition	
1703	41704	Digital input port 4definition	
1704	41705	Digital input port 5definition	
1705	41706	Digital input port 6definition	
1706	41707	Digital input port 7definition	
1707	41708	Digital input port 8definition	
1708	41709	Digital input port 9definition	
1709	41710	Digital input port 10definition	
1710	41711	Digital input port 11definition	
1711	41712	Digital input port 12definition	
1712	41713	Switch output port 1definition	write:

1713	41714	Switch output port 2definition	Write function corresponding value . If OUT is defined as running, write 1 in the corresponding register of OUT . read: Returns the current switch custom state
1714	41715	Switch output port 3definition	
1715	41716	Switch output port 4definition	
1716	41717	Switch output port 5definition	
1717	41718	Switch output port 6definition	
1718	41719	Switch output port 7definition	
1719	41720	Switch output port 8definition	
1720	41721	Switch output port 9definition	
1721	41722	Switch output port 10definition	
1722	41723	Switch output port 11definition	
1723	41724	Switch output port 12definition	
1724	41725	Switch output port 13definition	
1725	41726	Switch output port 14definition	
1726	41727	Switch output port 15definition	
1727	41728	Switch output port 16definition	
1728	41729	Start / end switch test	write: The stop state can be written . Write 1 to start the switch test . The switch test state. Press input and output ports the input and output test registers, defined functions not performed. In the switch test state, write 0 to exit the switch test state . The input and output ports perform the defined functions . Read: Returns the status of the current switch test switch .
1729	41730	Input switch test	Write: not allowed to write Read: From the low to the high, the corresponding port IN1~12 input . 1 is valid for input, 0 is invalid for input .
1730	4173	Output switching test	Write: The switch test switch can be written in the open state, and the output from the low to the high port corresponds to the port OUT1~16 . 1 is valid for output, 0 is invalid for output . Read: Returns the status of the current output switch port, from the low to the high, respectively, corresponding to the port OUT1~16 output . 1 is valid for output, 0 is invalid for output .
1731	41732		
1732~1799	41733~41800	Reserved	
Other parameter settings (reserved 1900~2000)			
1800	41801	Total print total	Read as 0 Write 1 , total print total

1801	41802	Print recipe accumulation	Read as 0 Write 100 to print the current recipe accumulation Write 1-20 , print the corresponding formula accumulation Write 101 to print all recipes	
1802	41803	Print user accumulation	Read as 0 Write 100 to print the current user cumulative Write 0-9 , print the corresponding user cumulative Write 101 , print all user cumulative	
1803	41804	reset	8800 all parameters (including school scales) 8801 all parameters (excluding calibration scales included) 8802 reset recipe parameters 8803 reset system and communication 8804 reset peripheral parameters 8805 reset motor parameters 880 6 reset calibration scale 880 7 reset switch 880 8 reset auxiliary logic parameters	
1804	41805	Parameter backup	read: 0: There is no backup parameter currently; 1: There are currently backup parameters. write: Write 9900 execution parameter backup; Write 9901 to perform a recovery backup; Write 9902 to perform a delete backup .	
1805	41806	Backup date		Read only
1806	41807			
18 07	41808	Backup time		
1808	41809			
1809	41810	year	0 -99	
1810	41811	month	1 -12	
1811	41812	day	1 -31	
1812	41813	Time	0-23	
1813	41814	Minute	0 -59	
1814	41815	second	0 -59	
1815	41816	Clear total accumulation	Write 1 clear total accumulation	
1816	41817	Clear recipe accumulation	Write 1-20 to clear the corresponding accumulated data ; Write 100 to clear the current recipe accumulation ; Write 101 clears all recipe accumulations .	

1817	41818	Clear user accumulation	Read as 0 . Write 0-9 to clear the corresponding user accumulation ; Write 100 to clear the current user accumulation ; Write 101 clears all user accumulations .
Batch setting			
1950	41951	batch	Initial value: 0 ; range: 0 ~ 50000 .
1951	41952	Remaining batch	Read only
1952~1999	41953~42000	Reserved	
Formula target value (reserved 2000~2300)			
2000	42001	Formula 1 target value	Initial value : 0 .
2001	42002		
2002	42003	Recipe 2 target value	Initial value : 0 .
2003	42004		
.....		
2038	42039	Recipe 20 target value	Initial value : 0 .
2039	42040		
Cumulative weight			
2040	42041	Total cumulative weight is 6 digits	Read only
2041	42042		
2042	42043	The total cumulative weight low 9	
2043	42044		
2044	42045	Total accumulated number of packets	Read only
2045	42046		
2046	42047	Formula 1 cumulative weight is 6 digits high	Read only
2047	42048		
2048	42049	Formulation 1 cumulative weight low 9	
2049	42050		
2050	42051	Formula 1 cumulative count	
2051	42052		
.....		
2160	42161	Formulation 6 High 20 cumulative weight	
2161	42162		
2162	42163	Formulation 20 cumulative weight low 9	
2163	42164		
2164	42165	Formula 20 cumulative times	
2165	42166		

User cumulative weight and number of times			
2166	42167	User 0cumulative weight is 6digits high	Read only
2167	42168		
2168	42169	User 0cumulative weight is 9digits lower	
2169	42170		
2170	42171	User 0cumulative times	
2171	42172		
2172	42173	User 1 has acumulative weight of 6digits	
2173	42174		
2174	42175	1 usercumulative weight low 9	
2175	42176		
2176	42177	User 1cumulative count	
2177	42178		
2178	42179	User 2cumulative weight is 6digits high	
2179	42180		
2180	42181	2 usersaccumulated weight low 9	
2181	42182		
2182	42183	User 2cumulative times	
2183	42184		
2184	42185	User 3cumulative weight is 6digits	
2185	42186		
2186	42187	Usercumulative weight low 93	
2187	42188		
2188	42189	User 3cumulative times	
2189	42190		
2190	42191	User 4cumulative weight is 6digits	
2191	42192		
2192	42193	4 usersaccumulated weight low 9	
2193	42194		
2194	42195	User 4cumulative times	
2195	42196		
2196	42197	User 5cumulative weight is 6digits	
2197	42198		
2198	42199	Usercumulative weight low 95	
2199	42200		
2200	42201	User 5cumulative times	
2201	42202		
2202	42203	User 6cumulative weight is 6digits	
2203	42204		

2204	42205	6 usersaccumulated weight low 9	
2205	42206		
2206	42207	User 6cumulative times	
2207	42208		
2208	42209	User 7cumulative weight is 6digits	
2209	42210		
2210	42211	Usercumulative weight low 97	
2211	42212		
2212	42213	User 7cumulative times	
2213	42214		
2214	42215	User 8cumulative weight is 6digits	
2215	42216		
2216	42217	8 userscumulative weight low 9	
2217	42218		
2218	42219	User 8cumulative times	
2219	42220		
2220	42221	User 9cumulative weight is 6digits	
2221	42222		
2222	42223	Usercumulative weight low 99	
2223	42224		
2224	42225	User 9cumulative times	
2225	42226		
2226~2299	42227~42300	Reserved	
Compile information (reserved 9000~9100)			
9000	49001	Background version number	For example : 0 1000 0
9001	49002		
9002	49003	Background compilation date	For example : 161201
9003	49004		
9004	49005	Background compile time	For example : 130805
9005	49006		
9006	49007	Additional version number	For example : 100
9007	49008		
9008~9099	49009~49100	Reserved (reserved 9100~9200)	
Coil address (reserved 0~100)			
0	40001	start up	
1	40002	Emergency stop	
2	40003	Slow stop	
3	40004	time out	
4	40005	Clear	
5	40006	Clear alarm	

6	40007	Clip pocket	This address can only be written to 1 . Read 1 is valid and 0 is invalid.
7	40008	Selection formula	
8	40009	Manual slow addition	
9	40010	Manually add	
10	40011	Manual unloading	
11	40012	Manual cleaning	
12	40013	Hanging bag	
13	40014	Sewing machine start	
14	40015	Sewing machine emergency stop	
15	40016	Auxiliary pulse function 1	
16	40017	Auxiliary pulse function 2	
17	40018	Auxiliary pulse function 3	
18	40019	Auxiliary pulse function 4	
19	40020	Clear advance information	
...	
80	40081	Clear current user accumulation	Write 1 is valid.
81	40082	Clear all users	
82	40083	Clear current formula accumulation	
83	40084	Clear all formula accumulation	
84	40085	Total accumulation	
...	
100	40101	Reset all parameters	Write 1 is valid
101	40102	Calibration parameter reset	
102	40103	System and communication parameters reset (not including communication parameters)	
103	40104	Recipe parameter reset	
104	40105	Peripheral parameter reset	
105	40106	Switching parameter reset	
106	40107	Motor parameter reset	
107	40108	Auxiliary logic parameter reset	
108	40109	Perform parameter backup	
109	40110	Restore backup parameters	
110	40111	Delete backup parameters	This address can only be written to 1 to delete backup parameters. Read 1 has backup parameters; Read 0 as no backup parameter .
Coil switch test (reserved 200~250)			
150	40151	Switching test switch: When writing into the test switch 1; 0 is written to exit. Not writable at runtime	
151	40152	When input port 1 is valid, it reads 1 ; if it is invalid, it is 0 .	Does not take effect when writing.
152	40153	When input port 2 is valid, it reads 0 ; if it is invalid, it is 0 .	

153	40154	When input port 3 is valid, it is read as 1 ; if it is invalid, it is 0 .	
154	40155	When input port 4 is valid, it reads 1 ; if it is invalid, it is 0 .	
155	40156	When input port 5 is valid, it reads 1 ; if it is invalid, it is 0 .	
156	40157	When input port 6 is valid, it reads 1 ; if it is invalid, it is 0 .	
157	40158	When input port 7 is valid, it reads 1 ; if it is invalid, it is 0 .	
158	40159	When input port 8 is valid, it reads 1 ; if it is invalid, it is 0 .	
159	40160	When input port 9 is valid, it reads 1 ; if it is invalid, it is 0 .	
160	40161	When input port 10 is valid, it is read as 1 ; if it is invalid, it is 0 .	
161	40162	When input port 11 is valid, it is read as 1 ; if it is invalid, it is 0 .	
162	40163	When input port 12 is valid, it reads 1 ; if it is invalid, it is 0 .	
163	40164	When writing 1 , output port 1 is valid; when writing 0 , output port 1 is invalid.	
164	40165	When writing 1 , output port 2 is valid; when writing 0 , output port 2 is invalid.	
165	40166	When writing 1 , the output port 3 is valid; when writing 0 , the output port 3 is invalid.	
166	40167	When writing 1 , the output port 4 is valid; when writing 0 , the output port 4 is invalid.	
167	40168	When writing 1 , output port 5 is valid; when writing 0 , output port 5 is invalid.	
168	40169	When writing 1 , the output port 6 is valid; when writing 0 , the output port 6 is invalid.	
169	40170	When writing 1 , the output port 7 is valid; when writing 0 , the output port 7 is invalid.	
170	40171	When writing 1 , output port 8 is valid; when writing 0 , output port 8 is invalid.	
171	40172	When writing 1 , the output port 9 is valid; when writing 0 , the output port 9 is invalid.	
172	40173	When writing 1 , the output port 10 is valid; when writing 0 , the output port 10 is invalid.	
173	40174	When writing 1 , the output port 11 is valid; when writing 0 , the output port 11 is invalid.	
174	40175	When writing 1 , the output port 12 is valid; when writing 0 , the output port 12 is invalid.	
175	40176	When writing 1 , the output port 13 is valid; when writing 0 , the output port 13 is invalid.	
176	40177	When writing 1 , the output port 14 is valid; when writing 0 , the output port 14 is invalid.	
177	40178	When writing 1 , the output port 15 is valid; when writing 0 , the output port 15 is invalid.	
178	40179	When writing 1 , the output port 16 is valid; when writing 0 , the output port 16 is invalid.	

Note 2: The meter will perform the weightless gain calibration according to the currently stored sensor power supply voltage, sensor sensitivity, and sensor maximum range (where the maximum range input cannot be greater than the maximum range set in the meter calibration (modbus addresses 10104 and 40105)).

Calibration principle:

Zero calibration: Zero calibration can be performed via modbus (40106 and 40107) addresses. (If you skip the zero calibration and directly perform the weightless gain calibration, the last recorded zero will be used as the current zero calibration)

Gain calibration: Gain millivolts is the input sensor power multiplied by the sensor sensitivity, and the gain weight is the sensor's maximum range. The gain millivolts and gain weight used for gain scaling here are referenced below.

The first type of weightless gain calibration method: when the sensor power supply (5000mv) is input separately, the weightless calibration operation will be directly performed.

The second type of weightless gain calibration method: input sensor sensitivity (2mv/v) and input the sensor's maximum range (1000kg) will carry out the weightless calibration operation (note here, please input only the sensor sensitivity or only input the maximum range). When the range is measured, the entered value is not saved immediately. Only when both values are entered and the two values entered are reasonable, the data is saved and then the gain calibration is performed.